Fort.	9-331
+May	1963

## UP ED STATES

SUBMIT IN TRI

Form approved.

,11.11	DEPARTME OF THE INTERIOR (Other instructic on re-	Budget Burea	n No. 42-R1424.
	DEPARTME OF THE INTERIOR (Other instructio on re-	5. LEASE DESIGNATION	AND SEE AL NO.
	GEOLOGICAL SURVEY	NM 0234351	
	SUNDRY NOTICES AND REPORTS ON WELLS  (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  Use "APPLICATION FOR PERMIT—" for such proposals.)	6. IF INDIAN, ALLOTTES	OR TRIBE NAME
	WELL XX WELL OTHER	7. UNIT AGREEMENT NA	ME
2.	NAME OF OPERATOR	8. FARM OR LEASE NAM	E
	Tom Brown, Inc.	Federal	
3	ADDRESS OF OPERATOR	9. WELL NO.	
	P. O. Box 2608, Midland, Texas 79702	1	
4. :	P. O. Box 2608, Midland, Texas 79702  LOCATION OF WELL (Report location clearly and in accordance with any State regular metrics)  At surface 6600, FMI 8, 6601, FMI	10. FIELD AND POOL, OR	WILDCAT
	At surface 660' FNL & 660' FWL	Vada Penn	
	ave the	11 0FC M D 15 0D D	LK. AND
	PER IIT NO. 15. ELEVATIONS (Show whether DF, RT, do S GEOLOGICAL SURV HOBBS, NEW MEXIC	<b>)</b> Sec. 33, T8S	, R36E
14. 1	PER HT NO. 15. ELEVATIONS (Show whether DF, RT, de etc.) ORBS, NEW MARKET NO.	12. COUNTY OR PARISH	13. STATE
	4116' HODE	Roosevelt	_ New Mexic
16.	Chad American D. T. I. It is No. 1		

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:			SUBSEQUENT REPORT OF:			
TEST WATER SHUT-OFF		PULL OR ALTER CSING		WATER SHUT-OFF	¬	ING WELL
FRACTURE TREAT		MULTIPLE COMPLETE		FRACTURE TREATMENT	_	NG CASING
SHOOT OR ACIDIZE		ABANDON*		SHOOTING OR ACIDIZING	Plug SABANA	
REPAIR WELL		CHANGE PLANS		(Other)	TITHE OFFER 124	VENT* ZX
(Other)				(Note: Report results Completion or Recomple	of multiple comple	tion on Well

17. DESCRIBE PROFOSED OF COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of scarting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and tones pertinent to this work.)\*

6-21-80 - Set squeeze tool at 5828'. Squeezed perfs. and collapsed pipe with 200 sxs C1 H cement.

7-29-80 - Cut  $4\frac{1}{2}$ " csg. at 4210'. Pulled and lay down csg.

7-30-80 - Spot 80 sxs plug at 4180'. Spot 50 sxs plug at 4022'. 7-31-80 - Cut 8 5/8" csg at 938.67'. Pulled and lay down csg.

8-1-80 - Spotted 60 sxs cement plug at 782', 60 sxs cement plug at 350' and 10 sxs plug at surface.

Install dry hole marker.

We will notify U.S.G.S. when the location is ready for inspection.

18.	I hexeby certify that the folegoing is tran and correct			<del></del>
=	SIGNED COMMENTS	TITLE Vice President	DATE _	August 5, 1980
	(Orig. Sgd.) PETER W. CHESTER	ACTING DISTRICT ENGINEER		NOV 1 8 19 <b>80</b>
	CONDITIONS OF APPROVAL, IF ANY:	TITLE	DATE _	1.0 . 5 0 1300