

EMERGENCY PROCEDURE

When the driller has decided a blowout threatens from any of the above-mentioned items, he should follow procedures used in blowout prevention drills. In addition, he should contact his supervisor as soon as possible, who in turn should contact Pzl's supervisor.

Contractor's and Pzl's supervisors should agree in advance on procedures to be followed. If agreed upon, Pzl's "Emergency Procedure for Blowout Prevention" and "Kick Control Work Sheet" should be posted at the well.

RECEIVED
OCT 19 1982
O.C.D.
HOBBS OFFICE

173