

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. LG-5550	
7. Unit Agreement Name	
8. Farm or Lease Name PETTIGREW 30	
9. Well No. 1	
10. Field and Pool, or Wildcat WILDCAT (SAN ANDRES)	
12. County ROOSEVELT	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator PIONEER PRODUCTION CORPORATION
3. Address of Operator P. O. BOX 2542 AMARILLO, TEXAS 79189	4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>NORTH</u> LINE AND <u>660</u> FEET FROM THE <u>EAST</u> LINE, SECTION <u>30</u> TOWNSHIP <u>7S</u> RANGE <u>35E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4239.1' GR 4250' KB	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Rig up workover rig. POOH with rods and pump. Lay rods down. POOH with tubing. Stand back. Plug well as follows:

1. Set cast iron bridge plug at 4150'.
2. RIH with tubing. Load casing with 10#/gallon salt gel.
3. Spot 35' cement plug on top of CIBP (4 sxs).
4. Pull tubing to 2400'. Spot 100' cement plug from 2400' - 2300' (10-1/2 sxs).
5. Pull tubing to 2050'. Spot 100' cement plug from 2050' - 1950' (10-1/2 sxs).
6. Pull tubing to 430'. Spot 100' cement plug from 430' - 330' (10-1/2 sxs).
7. Pull tubing to 103'. Spot 100' cement plug from 103' - 3' (10-1/2 sxs).

Cut off casing flange. Install 4" OD x 4' marker with Pioneer Production Corporation, Pettigrew 30 #1, Sec 30 - T7S - R35E, Unit Letter A, Roosevelt County welded or stamped on marker.

NOTE: Contact New Mexico Conservation Commission in Hobbs, NM 24 hours prior to doing this work.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry R. Sexton TITLE Sr. Production Engineer

DATE 01-16-85

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT 1 SUPERVISOR

TITLE

DATE

JAN 21 1985

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 18 1985

O.C.B.
HOBBS OFFICE