Form 3160-5 (June 1990)

UNITED STATES SCALE MANGE 86240

DEPARTMENT OF THE INTERIOR

The second second

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

	LAND MANAGEMENT	NM 51837
SUNDRY NOTICES AND REPORTS ON WELLS		6. If Indian, Allottee or Tribe Name
SUNDRY NOTICES	rill or to deepen or reentry to a different reservoir.	
o not use this form for proposals to u	PR PERMIT—" for such proposals	
- OSE AT LIGHTON		7. If Unit or CA, Agreement Designation
SUBMI	T IN TRIPLICATE	
To a C Well		
Type of Well Oil Well Well Other		8. Well Name and No.
Well Well Other Name of Operator		V. G. Kinahan Fed #1
Matador Operating Company		30-005-00504
A LL Talabasa No.		10. Field and Pool, or Exploratory Area
415 W. Wall, Ste 1101, Midland, TX 79701 (915) 687-5955		Cedar Point Wolfcamp
Location of Well (Footage, Sec., T., R., M., or Survey Description)		11. County or Parish, State
550 FGL 1000 FFL		Charries NIM
660 FSL; 1980 FEL		Chaves, NM
Sec 20-T15S-R30E	THE OF NOTICE REPO	BT OR OTHER DATA
CHECK APPROPRIATE BOX	((s) TO INDICATE NATURE OF NOTICE, REPO	7777, 077 0777
TYPE OF SUBMISSION	TYPE OF ACTION	
	Abandonment	Change of Plans
Notice of Intent	X Recompletion	New Construction
[X] a	Plugging Back	Non-Routine Fracturing
Subsequent Report	Casing Repair	Water Shut-Off
Final Abandonment Notice	Altering Casing	Conversion to Injection
Final Abandonment Notice	Other	Dispose Water (Note: Report results of multiple completion on Well
	e all pertinent details, and give pertinent dates, including estimated date of starti-	Completion or Recompletion Report and Log form.)
give subsurface locations and measured and the	Dazzi Dwill/wash to 8094 and find CIBI	P. Drill CIBP
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. Warmounts of formation w/ some cone off bit. GIH w/ tools	O77'. Drill/wash to 8094 and find CIBI Wash and drill to 8160 recovering cast of drilling mud. Spud on fish and POOH and attempt to retrieve junk, washing	P. Drill CIBP iron and large . Find shank and to 8167 recovering
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. Warmounts of formation w/ some cone off bit. GIH w/ tools	077'. Drill/wash to 8094 and find CIBI Wash and drill to 8160 recovering cast	P. Drill CIBP iron and large . Find shank and to 8167 recovering
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. Warmounts of formation w/ some cone off bit. GIH w/ tools	O77'. Drill/wash to 8094 and find CIBI Wash and drill to 8160 recovering cast of drilling mud. Spud on fish and POOH and attempt to retrieve junk, washing	P. Drill CIBP iron and large . Find shank and to 8167 recovering
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. was amounts of formation w/ some cone off bit. GIH w/ tools	O77'. Drill/wash to 8094 and find CIBN ash and drill to 8160 recovering casted drilling mud. Spud on fish and POOH and attempt to retrieve junk, washing rilling mud. POOH without junk, determing up wellhead. Release rig.	P. Drill CIBP iron and large . Find shank and to 8167 recovering mined to be outside OCT 2 21993
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. We amounts of formation w/ some cone off bit. GIH w/ tools heavy formation solids w/ dicasing. GIH w/ tbg and flame.	O77'. Drill/wash to 8094 and find CIBN ash and drill to 8160 recovering casted drilling mud. Spud on fish and POOH and attempt to retrieve junk, washing rilling mud. POOH without junk, determing up wellhead. Release rig.	P. Drill CIBP iron and large . Find shank and to 8167 recovering mined to be outside OCT 2 21993
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. wamounts of formation w/ some cone off bit. GIH w/ tools heavy formation solids w/ dicasing. GIH w/ tbg and flame.	O77'. Drill/wash to 8094 and find CIBN ash and drill to 8160 recovering casted drilling mud. Spud on fish and POOH and attempt to retrieve junk, washing rilling mud. POOH without junk, determing up wellhead. Release rig.	P. Drill CIBP iron and large . Find shank and to 8167 recovering mined to be outside OCT 2 21993
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. was amounts of formation w/ some cone off bit. GIH w/ tools heavy formation solids w/ dicasing. GIH w/ tbg and flam the foregoing three and perfect signed (This space for Federal or State office use)	O77'. Drill/wash to 8094 and find CIBN lash and drill to 8160 recovering casted drilling mud. Spud on fish and POOH and attempt to retrieve junk, washing rilling mud. POOH without junk, deteringe up wellhead. Release rig. Title Operations Manager Operations Manager NOV.	P. Drill CIBP iron and large . Find shank and to 8167 recovering mined to be outside OCT 2 21993
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. We amounts of formation w/ some cone off bit. GIH w/ tools heavy formation solids w/ dicasing. GIH w/ tbg and flam casing. GIH w/ tbg and flam (This space for Federal or State office use)	O77'. Drill/wash to 8094 and find CIBN wash and drill to 8160 recovering casted drilling mud. Spud on fish and POOH and attempt to retrieve junk, washing rilling mud. POOH without junk, determined up wellhead. Release rig. Title Operations Manager Title NOY	P. Drill CIBP iron and large. Find shank and to 8167 recovering mined to be outside OCT 2 21993 CHESTER 10-21-93
GIH w/ 4-3/4" bit. Tag @ 80 and fall through to 8113. We amounts of formation w/ some cone off bit. GIH w/ tools heavy formation solids w/ dicasing. GIH w/ tbg and flam casing. GIH w/ tbg and flam (This space for Federal or State office use) Approved by Conditions of approval, if any:	O77'. Drill/wash to 8094 and find CIBN lash and drill to 8160 recovering casted drilling mud. Spud on fish and POOH and attempt to retrieve junk, washing rilling mud. POOH without junk, deteringe up wellhead. Release rig. Title Operations Manager Operations Manager NOV.	P. Drill CIBP iron and large. Find shank and to 8167 recovering mined to be outside OCT 2 21993 OCT 2 21993 OCT 2 21993

OFFICE