

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
N. M. LAND RESOURCES COMMISSION
P.O. BOX 1980
HOBBS, NEW MEXICO 88240

Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-25363

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER RE-COMPLETION		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR McCLELLAN OIL CORPORATION		8. FARM OR LEASE NAME Champeau ^{mac} Federal	
3. ADDRESS OF OPERATOR P O Drawer 730, Roswell, NM 88202-0730		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FNL & 1980' FWL Unit C		10. FIELD AND POOL, OR WILDCAT Little Lucky Lake Morrow	
14. PERMIT NO. 30-005-00518		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3902 G.L.	
		11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA Sec. 31-T15S-R30E	
		12. COUNTY OR PARISH Chaves	
		13. STATE NM	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Re-Completion

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to:

1. Dig working pit.
2. Kill well with 2% KCL water and install B.O.P.S.
3. T.O.H. with tubing.
4. Set CIBP above existing perfs (9884-9901') at 9800' and dump 30' cement on top.
5. Perforate new zone (9333' - 9351') and TIH with packer and tubing
6. Test new zone, possible acid job will be performed.



18. I hereby certify that the foregoing is true and correct

SIGNED Mark McClellan

TITLE President

DATE 5-28-93

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
PETER V. DARTER

JUN 2 1993

*See Instructions on Reverse Side
BUREAU OF LAND MANAGEMENT
ROSWELL RESOURCE AREA