

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>B 10411 - 15</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name <b>S. Caprock Queen Unit</b>	
2. Name of Operator <b>Union Oil of California</b>		8. Farm or Lease Name <b>S. Caprock Queen Unit</b>	
3. Address of Operator <b>500 N. Marienfeld - Midland, Texas 79701</b>		9. Well No. <b>T-21, W-13, Sec. 20</b>	
4. Location of Well UNIT LETTER <b>M</b> <b>660</b> FEET FROM THE <b>S</b> <b>660</b> FEET FROM THE <b>W</b> <b>20</b> LINE, SECTION <b>15 S</b> RANGE <b>31 E</b> NMPM.		10. Field and Pool, or Wildcat <b>S. Caprock Queen Unit</b>	
15. Elevation (Show whether DF, BT, GR, etc.) <b>GL 4441</b>		12. County <b>Chaves</b>	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### Plugging Procedures Below:

1. 12 1/4" @ 200' W/200 Sx.
2. 7" @ 3100' W/125 Sx.
3. Perf. @ Open Hole 3100' - 3136'

Plug #1 - 30 Sx. @ 3100'  
Plug #2 - 5 Sx. @ Surface

Recovered 3000' Tubing

Establish Dry Hole Marker

H. D. Oden, Inc.

Agent for Union Oil  
of California

May 8, 1972

DATE

DATE

SEP 20 1972