

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator Union Oil Company of California	5. State Oil & Gas Lease No. E-8664
3. Address of Operator P. O. Box 671 - Midland, Texas 79701	7. Unit Agreement Name
4. Location of Well UNIT LETTER E, 1650 FEET FROM THE North LINE AND 330 FEET FROM THE West LINE, SECTION 29 TOWNSHIP 15 South RANGE 31 East N.M.P.M.	8. Farm or Lease Name South Caprock Queen Unit
15. Elevation (Show whether DF, RT, GR, etc.) 4432' GR.	9. Well No. Tract 48 Well No. 5
	10. Field and Pool, or Wildcat Caprock Queen
	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move in and rig up double drum pulling unit.
Pull rods and pump out of hole.
Circulate hole with 9.5# drilling mud.
Spot Plug No. 1 from 3,169' to 2,685' with 50 sx cement.
Pull tubing out of hole.
Free-point 5-1/2" OD Casing and cut off (at approximately 1,000').
Pull and lay down 5-1/2" OD Casing.
Run tubing and spot Plug No. 2 from 1,050' to 950' in and out of 5-1/2" OD Casing stub with 50 sx cement.
Pull tubing up to 370', spot Plug No. 3 from 370' to 260' with 50 sx cement.
Pull tubing out of hole.
Spot Plug No. 4 from 10' to surface with 10 sx cement.
Cut off casing head 2' below ground level and weld 1/2" steel plate on top of surface casing.
9.5# drilling mud to be placed between cement plugs.
Install 4" pipe marker with permanent location, according to N.M.O.C.C. regulations.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.R. Hughes TITLE District Drilling Supt. DATE February 5, 1975

APPROVED BY Joe D. [Signature] TITLE Dist. [Signature] DATE Feb. 5, 1975

CONDITIONS OF APPROVAL, IF ANY: Dist. [Signature]