

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E 5666</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name <b>S. Caprock Queen Unit</b>
2. Name of Operator <b>Union Oil of California</b>	8. Farm or Lease Name <b>S. Caprock Queen Unit</b>
3. Address of Operator <b>500 N. Marienfeld - Midland, Texas</b>	9. Well No. <b>T-39, W41, Sec. 30</b>
4. Location of Well UNIT LETTER <b>A</b> <b>660</b> FEET FROM THE <b>N</b> LINE AND <b>660</b> FEET FROM THE <b>E</b> LINE, SECTION <b>30</b> TOWNSHIP <b>15 S</b> RANGE <b>31 NE</b> NMPM.	10. Field and Pool, or Wildcat <b>S. Caprock Queen Unit</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>GL 4447 DF</b>	12. County <b>Chaves</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### Plugging Procedures Below:

1. 8 5/8" @ 300' W/200 Sx.
2. 5 1/2" @ 3100' W/400 Sx.
3. Perf. @ 3137' - 3151'

Plug #1 - 25 Sx. @ 3100'  
Plug #2 - 5 Sx. @ Surface

Recovered 3000' Tubing

Establish Dry Hole Marker

H. D. Oden, Inc.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Agent for Union Oil  
of California

August 12, 1971

SIGNED H. D. Oden

TITLE \_\_\_\_\_

DATE \_\_\_\_\_

APPROVED BY Nathan E. Clegg

TITLE OIL

DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

APR 4 1975

OIL CONSERVATION COMM.  
HOUSTON, N. M.