

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

30-005-00954

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		<p>5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/></p> <p>5. State Oil & Gas Lease No.</p>
<p>1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-</p> <p>2. Name of Operator Cities Service Oil Company</p> <p>3. Address of Operator Box 69 - Hobbs, New Mexico 88240</p> <p>4. Location of Well UNIT LETTER K, 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 14S RANGE 31E NMPM.</p>	<p>7. Unit Agreement Name D.Q.S.U.</p> <p>8. Farm or Lease Name Tract 19</p> <p>9. Well No. 1</p> <p>10. Field and Pool, or Wildcat Caprock Queen</p>	
<p>15. Elevation (Show whether DF, RT, GR, etc.) 4400 DF</p>		<p>12. County Chaves</p>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOBS ☐ OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The above well was plugged and abandoned in the following manner: (Plugged 4-27-70)

1. Set CI Bridge Plug @ 2860 (7" set @ 3050 w/100 sacks)
2. Set a 25 sack cement plug @ 2860-2738.
3. Load hole with mud laden fluid.
4. Shot and pulled 554' of 7" casing.
5. Set a 30 sack cement plug @ 600-450 (1/2 in and 1/2 out of 7" csg. stub)
6. Set a 90 sack cement plug @ 314-179 (1/2 in and 1/2 out of 12 1/4" surface stub)
7. Set a 10 sack cement surface plug @ 15-0 with a 4" marker extending 4" above the surface to designate a P & A location.
8. Location has been cleared of all debris and equipment and is ready for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED
C. D. ROBERTSON

SIGNED _____

TITLE **District Admin. Supervisor**

DATE **11/17/80**

APPROVED BY John W. Runyan

TITLE **Geologist**

DATE **FEB 24 1971**

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 20 1971

OIL CONSERVATION COMM.
HOBBS, N. M.