

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name <b>D.Q.S.U.</b>
8. Farm or Lease Name <b>Tract 45</b>
9. Well No. <b>4</b>
10. Field and Pool, or Wildcat <b>Caprock (Queen)</b>
12. County <b>Chaves</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection</b> <b>30-005-01041</b>
2. Name of Operator <b>Cities Service Oil Company</b>
3. Address of Operator <b>Box 69 - Hobbs, New Mexico 88240</b>
4. Location of Well UNIT LETTER <b>N</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>11</b> TOWNSHIP <b>14S</b> RANGE <b>31E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>4406 DF</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOBS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>
ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The above well was plugged and abandoned in the following manner: (Plugged 5-19-70)

1. Set a CI Bridge Plug @ 2995 (7" set @ 3055 w/1650 sx)
2. Set a 25 sack cement plug on top of bridge plug @ 2995-2845.
3. Loaded hole with mud laden fluid.
4. Set a 10 sack cement surface plug @ 30-0 with a 4" marker extending 4' above the surface to designate a P & A location.
5. Location has been cleared of all debris and equipment and is ready for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John W. Runyan TITLE District Admin. Supervisor DATE 11/17/70  
APPROVED BY John W. Runyan TITLE Geologist DATE 1971  
CONDITIONS OF APPROVAL, IF ANY: