

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		<p>5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/></p> <p>5. State Oil & Gas Lease No.</p>
<p>1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-</p>	<p>7. Unit Agreement Name D.Q.S.U.</p>	
<p>2. Name of Operator Cities Service Oil Company</p>	<p>8. Farm or Lease Name Tract 47</p>	
<p>3. Address of Operator Box 69 - Hobbs, New Mexico 88240</p>	<p>9. Well No. 3</p>	
<p>4. Location of Well UNIT LETTER E 1980 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 11 TOWNSHIP 14S RANGE 31E NMPM.</p>	<p>10. Field and Pool, or Wildcat Caprock Queen</p>	
<p>15. Elevation (Show whether DF, RT, GR, etc.) 4409 GR</p>		<p>12. County Chaves</p>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The above well was plugged and abandoned in the following manner:

1. Set a CI Bridge Plug @ 2991. (7" set @ 3046 w/125 sxs)
2. Set a 25 sack cement plug on top of bridge plug @ 2991-2886.
3. Loaded hole with mud laden fluid.
4. Set a 10 sack cement surface plug @ 30-0 with a 4" marker extending 4' above the surface to designate a P & A location.
5. Location has been cleared of all debris and equipment and is ready for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *E. Pender* TITLE District Manager DATE 10/23/70

APPROVED BY *John A. Runyan* TITLE 1001 10/23/70 DATE 10/23/70

CONDITION OF APPROVAL, IF ANY:

RECEIVED

SEP 28 1970

OIL CONSERVATION COMM.
HOBBES R. 111