

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

N. M. O. C. C. COPY
SUBMIT IN TRIPLIC.
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		30-005-01057	
2. NAME OF OPERATOR Cities Service Oil Company			
3. ADDRESS OF OPERATOR Box 69 - Hobbs, New Mexico 88240			
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FSL and 1980' FEL of Sec. 15-T14S-R31E, Chaves County, New Mexico			
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4424 DF	
12. COUNTY OR PARISH Chaves		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☒

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The above well was plugged and abandoned in the following manner: (Plugged 4-16-70)

1. Set a CI Bridge Plug @ 2975' (7" set @ 3075 w/125 sacks).
2. Loaded hole with mud laden fluid.
3. Set a 30 sack cement plug @ 2975-2850.
4. Shot and pulled 1008' 7" casing.
5. Set a 30 sack cement plug @ 1083-933 ($\frac{1}{2}$ in and $\frac{1}{2}$ out of 7" csg. stub)
6. Set a 30 sack cement plug @ 500-410.
7. Set a 90 sack cement plug @ 310-200 ($\frac{1}{2}$ in and $\frac{1}{2}$ out of 12 $\frac{1}{4}$ " surface stub)
8. Set a 10 sack cement surface plug @ 15-0 with a 4" marker extending 4' above the surface to designate a P & A location.
9. Location has been cleared of all debris and equipment and ready for final inspection.

18. I hereby certify that the foregoing is true and correct

SIGNED

ORIGINAL SIGNED
Q. D. ROBERTSON

TITLE **District Admin. Superv.**

DATE **11/17/70**

(This space for Federal or State office use)

APPROVED
ADDITIONAL APPROVALS, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963 - O-685229

847-485

RECEIVED

FEB 6 1971

OIL CONSERVATION COMMISSION
HARRIS, TEXAS

D. C. C.
ARTESIAN OFFICE