

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name <b>D.O.S.U.</b>
2. Name of Operator <b>Cities Service Oil Company</b>		8. Farm or Lease Name <b>Tract 33</b>
3. Address of Operator <b>Box 69 - Hobbs, New Mexico 88240</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>K</b> , <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>16</b> TOWNSHIP <b>14S</b> RANGE <b>31E</b> NMPM.		10. Field and Pool, or Wildcat <b>Carrick Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4184 Gr.</b>		12. County <b>Chaves</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The above well was plugged and abandoned in the following manner: (Plugged 6-10-70)

1. Set a CI Bridge Plug @ 2774 (7" set @ 2833 w/125 sxs)
2. Set a 25 sack cement plug on top of bridge plug @ 2774-2649.
3. Loaded hole with mud laden fluid.
4. Set a 10 sack cement surface plug @ 30-0 with a 4" marker extending 4' above the surface to designate a P & A location.
5. Location has been cleared of all debris and equipment and is ready for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John W. Runyan TITLE District Admin. Supervisor DATE 11/12/70

APPROVED BY John W. Runyan TITLE Asst. Dir. DATE FEB 24 1971  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 21 1971

OIL CONSERVATION COM. IL.  
ROCKFORD, IL. IL.