

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection</b>	7. Unit Agreement Name <b>D.Q.S.U.</b>
2. Name of Operator <b>Cities Service Oil Company</b>	8. Farm or Lease Name <b>Tract 34</b>
3. Address of Operator <b>P. O. Box 69 - Hobbs, New Mexico 88240</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>D</b> , <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>16</b> TOWNSHIP <b>14S</b> RANGE <b>31E</b> NMPM.	10. Field and Pool, or Wildcat <b>Caprock Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>-</b>	12. County <b>Chaves</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The above well was plugged and abandoned in the following manner:

1. Squeezed open hole (2782-2800) w/150 sacks cement.
2. Set a CI Bridge Plug @ 2719 (5½" set @ 2782 w/125 sxs)
3. Set a 25 sack cement plug on top of bridge plug @ 2719-2500.
4. Loaded hole with mud laden fluid.
5. Set a 10 sack cement surface plug @ 30-0 with a 4" marker extending 4' above the surface to designate a P & A location.
6. Location has been cleared of all debris and equipment and is ready for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____	TITLE <b>District Admin. Supervisor</b>	DATE <b>11/12/70</b>
APPROVED BY <b>John W. Runyan</b>	TITLE <b>Logist</b>	DATE <b>FEB 24 1971</b>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

SEP 21 1970

OIL CONSERVATION COMM.  
WASH. D. C.