

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>

5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name <b>D.Q.S.U.</b>
2. Name of Operator <b>Cities Service Oil Company</b>	8. Farm or Lease Name <b>Tract 43</b>
3. Address of Operator <b>Box 69 - Hobbs, New Mexico 88240</b>	9. Well No. <b>3</b>
4. Location of Well UNIT LETTER <b>J</b> , <del>1980</del> <b>2310</b> FEET FROM THE <b>South</b> LINE AND <del>1980</del> <b>2310</b> FEET FROM THE <b>East</b> LINE, SECTION <b>22</b> TOWNSHIP <b>14S</b> RANGE <b>31E</b> NMPM.	10. Field and Pool, or Wildcat <b>Caprock Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>-</b>	12. County <b>Chaves</b>

16.

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The above well was plugged and abandoned in the following manner: (Plugged 6-24-70)

1. Set a CI Bridge Plug @ 2940 (7" set @ 3094 w/100 sxs)
2. Set a 25 sack cement plug on top of bridge plug @ 2940-2815.
3. Loaded hole with mud laden fluid.
4. Set a 10 sack cement surface plug @ 30-0 with a 4" marker extending 4' above the surface to designate a P & A location.
5. Location has been cleared of all debris and equipment and is ready for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED \_\_\_\_\_ TITLE **District Admin. Supervisor** DATE **11/17/70**

APPROVED BY John W. Remington TITLE **Geologist** DATE **FEB 24 1971**

CONDITIONS OF APPROVAL, IF ANY:

.....

.....

.....

.....

RECEIVED

JAN 21 1971

GEORGE WASHINGTON UNIVERSITY  
LIBRARY

.....