

N. OF COPIES RECEIVED	
DISTRIBUTION	
SAT. A FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Water Injection</u>		7. Unit Agreement Name <u>Eastcap Queen</u>
2. Name of Operator <u>MILLER & MILLER AUCTIONEERS, INC.</u>		8. Farm or Lease Name
3. Address of Operator <u>2525 Brenner Ave, Ft. Worth, Texas 76106</u>		9. Well No. <u>17</u>
4. Location of Well UNIT LETTER <u>N</u> <u>330</u> FEET FROM THE <u>South</u> LINE AND <u>1650</u> FEET FROM <u>West</u> THE <u>27</u> LINE, SECTION <u>14</u> TOWNSHIP <u>South</u> RANGE <u>31</u> East NMPM.		10. Field and Pool, or Wildcat <u>Caprock Queen</u>
15. Elevation (Show whether DF, RT, GR, etc.)		12. County <u>Chaves</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set bridge plug above perforations and cap with 35' cement.
Shot 4 1/2 casing at 780.10'. Set 100' cement plug. Place
100' cement plug at bottom of 8 5/8 casing. Cap with 10
sacks cement.

Cleaned and ready for inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE _____	DATE <u>2/4/75</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>OIL & GAS INSPECTOR</u>	DATE <u>JUN 24 1981</u>
CONDITIONS OF APPROVAL, IF ANY:		