

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
<b>Patent Land</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name <b>S. Caprock Queen Unit</b>
2. Name of Operator <b>Union Oil of California</b>	8. Farm or Lease Name <b>S. Caprock Queen Unit</b>
3. Address of Operator <b>500 N. Maricopa - Midland, Texas</b>	9. Well No. <b>T-54, W-16, Sec. 28</b>
4. Location of Well UNIT LETTER <b>P</b> , <b>330</b> FEET FROM THE <b>E</b> LINE AND <b>990</b> FEET FROM THE <b>E</b> LINE, SECTION <b>38</b> TOWNSHIP <b>14 S</b> RANGE <b>31 E</b> NMPM.	10. Field and Pool, or Wildcat <b>S. Caprock Queen Unit</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>GL 4319</b>	12. County <b>Chaves</b>

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### Plugging Procedures Below:

1. 8 5/8" @ 187' W/200 Sk.
2. 5 1/2" @ 3034' W/400 Sk.
3. Surf. @ 3008' - 3012'

Plug #1 - 25 Sk. @ Surf.  
Plug #2 - 5 Sk. @ Surface

Recovered 2400' Tubing

Establish Dry Hole Marker

H. D. Olan, Inc.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>H. D. Olan</u>	TITLE <u>Agent for Union Oil of California</u>	DATE <u>July 13, 1971</u>
APPROVED BY <u>John W. Remyan</u>	TITLE <u>Secretary</u>	DATE <u>MAY 28 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		

fd