

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
<b>Patent</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name <b>S. Caprock Queen Unit</b>
2. Name of Operator <b>Union Oil of California</b>	8. Farm or Lease Name <b>S. Caprock Queen Unit</b>
3. Address of Operator <b>500 N. Marlenfeld - Midland, Texas</b>	9. Well No. <b>T-55A, W-9, Sec. 29</b>
4. Location of Well UNIT LETTER <b>I</b> , <b>2310</b> FEET FROM THE <b>S</b> LINE AND <b>330</b> FEET FROM THE <b>E</b> LINE, SECTION <b>29</b> TOWNSHIP <b>14 S</b> RANGE <b>31 E</b> NMPM.	10. Field and Pool, or Wildcat <b>S. Caprock Queen Unit</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>GL 4827</b>	12. County <b>Chaves</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### Plugging Procedures Below:

1. 8 5/8" @ 264' W/200 Sx.
2. 5 1/2" @ 2912' W/300 Sx.
3. Perf. @ 2887' - 2893'

Plug #1 - 25 Sx. @ 2800'  
Plug #2 - 5 Sx. @ Surface

Recovered 2000' Tubing

Establish Dry Hole Marker

H. D. Oden, Inc.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>H. D. Oden</i>	TITLE <b>Agent for Union Oil of California</b>	DATE <b>August 12, 1971</b>
APPROVED BY <i>John W. Runyan</i>	TITLE <b>Geologist</b>	DATE
CONDITIONS OF APPROVAL, IF ANY:		