

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name <b>Eastcap Queen</b>
2. Name of Operator <b>MILLER &amp; MILLER AUCTIONEERS, INC.</b>	8. Farm or Lease Name
3. Address of Operator	9. Well No. <b>30</b>
4. Location of Well UNIT LETTER <b>J</b> <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>34</b> TOWNSHIP <b>14 South</b> RANGE <b>31 East</b> NMPM.	10. Field and Pool, or Wildcat <b>Caprock Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <b>Chaves</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set bridge plug above perforations and cap with 35' cement.  
Shot 5 1/2 casing at 680'. Set 100' cement plug. Place  
100' cement plug at bottom of 8 5/8 casing. Cap with 10  
sacks cement.

Cleaned and ready for inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>[Signature]</i>	TITLE	DATE <b>2/4/75</b>
APPROVED BY <i>[Signature]</i>	TITLE <b>OIL &amp; GAS COMMISSIONER</b>	DATE <b>FEB 4 1975</b>
CONDITIONS OF APPROVAL, IF ANY:		