

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E 7662	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Injection</u>		7. Unit Agreement Name Caprock Queen
2. Name of Operator LEWIS B. BURLESON, INC.		8. Farm or Lease Name State A
3. Address of Operator P. O. Box 2479 - Midland, Texas 79702		9. Well No. #3
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>34</u> TOWNSHIP <u>14 South</u> RANGE <u>31 East</u> NMPM.		10. Field and Pool, or Wildcat Caprock Queen
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 2975' w/35' cmt. cap.
2. Circ hole w/brine and mud.
3. Set CIBP @ 260'
4. Perf. 267'.
5. Spot 72 sks. Class C cmt. plug to establish circ.
6. Circ w/64 sks. Class C cmt. in and out of pipe.
7. Install marker.
8. Clean location.

This procedure was approved by your Hobbs office and your field man who witnessed this operation.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CHECKED L.B. Burleson TITLE Lewis B. Burleson, President DATE Sept. 9, 1987

APPROVED BY Jack Griffin TITLE OIL & GAS INSPECTOR DATE 0915 1987

CONDITIONS OF APPROVAL, IF ANY: