

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-005-10097
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-8256

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> Propose to P&A	7. Lease Name or Unit Agreement Name McAlester AAH State
2. Name of Operator YATES PETROLEUM CORPORATION	8. Well No. 1
3. Address of Operator 105 South Fourth Street - Artesia, NM 88210	9. Pool name or Wildcat Tobac Penn
4. Well Location Unit Letter <u>D</u> : <u>553.5</u> Feet From The <u>North</u> Line and <u>561.3</u> Feet From The <u>West</u> Line Section <u>34</u> Township <u>8S</u> Range <u>33E</u> NMPM Chaves County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4381' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
1. Notify NMOCD, Hobbs, prior to job
 2. GIH with tbg. to 5700'
 3. If hole is taking fluid on vacuum down the tbg. then proceed. If not, notify NMOCD and talk to Jerry Sexton.
 4. Pump 200 sx. cmt. down tbg. WOC
 5. Tag up. If cmt is above top of fish (at 5890'), then proceed. If cmt not above top of fish, then pump more cement if still on a vacuum. If not on vacuum, then call NMOCD.
 6. Perforate 5 1/2" csg. at 3829'. Set cmt. retainer at 3729'. Pump 100' cmt. plug inside and outside 5 1/2" csg.
 7. Perforate 5 1/2" csg. at 435'. Set cmt retainer at 335'. Pump cmt. plug inside and outside 5 1/2" csg.
 8. Set 10 sx. surface plug & install P&A marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein (by: Pamela Evans) TITLE Production Clerk DATE 10-21-94
TYPE OR PRINT NAME Rusty Klein (by: Pamela EVANS) TELEPHONE NO. 505-748-1471

(This space for State Use)

APPROVED BY _____ TITLE _____

NOV 30 1994

DATE _____