

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E-10075</b>
7. Unit Agreement Name
8. Farm or Lease Name <b>State "A"</b>
9. Well No. <b>1</b>
10. Field and Pool, or Wildcat <b>Tobac SA West</b>
12. County <b>Chaves</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator <b>TOM L. INGRAM</b>
3. Address of Operator <b>P. O. Box 1757, Roswell, New Mexico 88201</b>
4. Location of Well UNIT LETTER <b>0</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>26</b> TOWNSHIP <b>8S</b> RANGE <b>32E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>4412 Gr</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work performed October 9, 1968 through October 10, 1968.

Set 25 sx. plug at 3900'.  
Shot casing @ 3000'  
" " @ 2500'  
" " @ 2000'  
" " @ 1500'  
" " @ 1113'

Pulled 4½" casing from 1113' to surface. Set 25 sack plug at 1113'.  
25 sack plug @ 350 in and out at the base of 8-5/8".  
A 10 sack plug at the surface.  
Heavy mud was used between plugs. Set marker and cleaned location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Tom L. Ingram TITLE Operator DATE October 18, 1968  
APPROVED BY John W. Runyan TITLE \_\_\_\_\_ DATE 10/23/1968  
CONDITIONS OF APPROVAL, IF ANY: