

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLI  
(Other instructions  
reverse side)Form approved.  
Budget Bureau No. 42-R1424.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
EFFECTIVE APPLICATION FOR PERMIT for such proposals.)

SUN OIL COMPANY - OX DIVISION

OIL GAS  
WELL NAME WELL OTHER

2. NAME OF OPERATOR

SUN OIL COMPANY  
Sundray OX Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 1416 - Roswell, New Mexico 75721

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)

At surface

660' FNL & 660' FEL of Section 10, T-8-S, R-33-E  
Chaves County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4396 DF

5. LEASE DESIGNATION AND SERIAL NO.

N. M. 025576

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

New Mexico "X" Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Chaveroo

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 10, T-8-S, R-33-E

12. COUNTY OR PARISH

Chaves

13. STATE

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐  
☐  
☐  
☐

PULL OR ALTER CASING

☐  
☐  
☐  
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐  
☐  
☐  
☐

REPAIRING WELL

☐  
☐  
☐  
☐

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

Produce Additional Section

X

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Moved in workover rig.
2. Pulled rods and tubing.
3. Drilled out Cast Iron Bridge Plug @ 4370'. Found cement under plug.
4. Abandon project. New PBD @ 4373'.
5. Run rods and tubing.
6. Put well on production. (COMPLETE 1-1-68)

18. I hereby certify that the foregoing is true and correct

SIGNED

R. L. Maness

TITLE

Acting District Engineer

DATE

January 3, 1968

(This space for Federal or State office use)

APPROVED BY

TITLE

APPROVED

DATE

CONDITIONS OF APPROVAL, IF ANY:

JAN 4 1968

\*See Instructions on Reverse Side

J L GORDON  
ACTING DISTRICT ENGINEER

## Instructions

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.