

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION C.

JUN 29 2 23 PM '67

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>	
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name Schuman	
9. Well No. 1	
10. Field and Pool, or Wildcat Wildcat	
12. County Chaves	

### SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator Cactus Drilling Corp. of Texas 3552
3. Address of Operator P.O. Box 2068 Hobbs, New Mexico
4. Location of Well UNIT LETTER E 1980 FEET FROM THE N LINE AND 660 FEET FROM THE W LINE, SECTION 29 TOWNSHIP 7s RANGE 31e NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4302 GI

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

rig up casing pulling unit and set 30 sx plug 3730 to 3300 inside of 4 1/2" pipe. Shot off pipe at 3100 feet and set 25 sx plug in and out of 4 1/2" stub. Set 25 sx plug at 1800 feet and 25 sx plug in and out of 8 5/8" surface casing at 350'. Set 10 sx plug at the surface with a dry hole marker on top. Clean and ~~ABANDON~~ abandon location.

3 c Reg KS 344  
5-6-98 to delete this  
API. file  
operator

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Leo H. Baker TITLE Vice-President DATE 6-29-67

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: