

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>K-3259</b>
7. Unit Agreement Name
8. Farm or Lease Name <b>New Mexico "J" State</b>
9. Well No. <b>1</b>
10. Field and Pool, or Wildcat <b>Cato San Andres</b>
12. County <b>Chaves</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator <b>Sun Oil Company</b>
3. Address of Operator <b>P. O. Box 2792, Odessa, Texas 79760</b>
4. Location of Well UNIT LETTER <b>K</b> <b>1980</b> FEET FROM THE <b>West</b> LINE AND <b>1980</b> FEET FROM THE <b>South</b> LINE, SECTION <b>36</b> TOWNSHIP <b>78</b> RANGE <b>30E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>Gr. 4201</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <b>Acidize perfs. 3591-3689</b> <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 12-14-68: Pull rods, tubing and packer.**
- 12-15-68: Run tubing, seat @ 3562 - packer set @ 3554.  
Acidize w/5000 gals. 28% NE Hcl acid. Flushed with fresh water.**
- 12-16-68: Pull tubing & Packer. Re-run 116 jts. 2-3/8" tbg, seat @ 3680. Run rods and pump. Well pumping @ 4:00 PM.**

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Eril Brandes* TITLE **Petroleum Engineer** DATE **12-23-68**

APPROVED BY *Joe V. Ames* TITLE \_\_\_\_\_ DATE **DEC 26 1968**

CONDITIONS OF APPROVAL, IF ANY: