

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Orig&2cc: OCC, Hobbs
cc: Regional Office
cc: file

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name J. G. O'Brien 198
9. Well No. 1
10. Field and Pool, or Wildcat Undesignated
12. County Chaves

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	
2. Name of Operator Sinclair Oil & Gas Company	
3. Address of Operator P. O. Box 1920, Hobbs, New Mexico 88240	
4. Location of Well UNIT LETTER <u>1</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>31</u> TOWNSHIP <u>8S</u> RANGE <u>30E</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

TD 3500', PBD 3462. Presently completed in San Andres perfs. 3240-3315' as shut-in well.

2-5/8"OD 20# SP-40 casing set @ 295' and cemented w/200 sks to surface.

4-1/2"OD 9.5# J-55 casing set @ 3500' and cemented w/300 sacks. Cement approx. 2460' fr surf.

PROPOSE TO PLUG AND ABANDON AS FOLLOWS:

Fill casing w/heavy mud between plugs.

Set C.I. plug @ approx. 3100' and dump 2 sacks cement on top.

Cut off 2-5/8"OD and 4-1/2"OD casing 2 foot below ground level and spot 10 sacks cement plug in top 20' of 4-1/2"OD casing.

Install regulation dry hole marker, clean and level location.

*Perfs must be sealed off from formation - 25-30 SKS
Cement at T.D. to come up and cover perfs.*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Lee B. [Signature] TITLE Superintendent

DATE 4-11-68

APPROVED BY John W. Runyan [Signature]
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE