ENERGY AND MINERALS DEPARTMENT					Form C-103
NO. OF COPIES RECEIVED	OIL CONSERVAT	ON DIVISION			Revised 10-1-78
DISTRIBUTION	DECEIVE POST OFFICE	BOX 2088			
SANTA FE	RECEIVED BY OFFICE	MEXICO 87501			
FILE	DED 17 1000			5a. Indicate	Type of Lease
U.S.G.S	<b>DEC 17</b> 1985			State X	Fee
LAND OFFICE	Q. C. D.			5. State Oil	& Gas Lease No.
OPERATOR				K-	745
SUNDRY NATICES AND REPORTS ON WELLS				xxxxxxxxxxxxxxxxxxxxxxxxxxxxx	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT				xxxxxxxxxxxxxxxxxxxxxxxx	
RESERVOIR. USE "APPLICATION FOR PERMIT-" (FORM C-101) FOR SUCH PROPOSALS)				xxxxxxxxxxxxxxxxxxxxxxxxxxx	
1. OIL GAS				7. Unit Agreement Name	
WELL X WELL OTHER					
2. Name of Operator				8. Farm or Lease Name	
Read & Stevens, Inc.				Sun "16" State	
3. Address of Operator				9. Well No.	
Post Office Box 1518, Roswel	I, New Mexico 88202			1	
4. Location of Well					Pool, or Wildcat
UNIT LETTER L . 1980 FEET FROM THE South LINE AND 660 FEET FROM				Siete San Andres	
THE West LINE. SECTION	16 TOWNSHIP 8S	RANGE	31E NMPM		XXXXXXXXXXXXXXXXX
xxxxxxxxxxxxxxxxxxxxxxxx				12. County	XXXXXXXXXXXXXXXXX
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	422 propriate Box To Indicate N	20.5'GR		Chaves	xxxxxxxxxxxxxxxx
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER  Describe Proposed or Completed Operations(Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.  Plugging and Abandoning Procedure  1) Set CIBP @ 3700', cap with 35' cement placed with dump bailer  2) Circulate hole with salt gel mud  3) Spot 25sx Class "C" cement, 1200'-1000' 4) Spot 10sx, surface plug @ 50' 5) Install Dryhole Marker 6) Clean location and prep for inspection					
I hereby certify that the info		complete to the b			ief. December 16, 1985
				Ul	EC 2 3 1985
ADDDOVED DV	TITLE		<del></del>	DATE	

CONDITIONS OF APPROVAL, IF ANY:

