

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-005-20531
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-5988
7. Lease Name or Unit Agreement Name Sam State Com.
8. Well No. #2
9. Pool name or Wildcat Vest Ranch Qn Assoc.
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER
2. Name of Operator McCellan Oil Corp.
3. Address of Operator P.O. Drawer 730 Roswell, NM 88202
4. Well Location Unit Letter <u>P</u> : <u>660</u> Feet From The <u>South</u> Line and <u>660</u> Feet From The <u>east</u> Line Section <u>32</u> Township <u>14s</u> Range <u>30e</u> NMPM <u>Chaves</u> County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set CIBP @ 2050'
- 2) Circulate hole with brine gell
- 3) Spot 50 sxs "C" on CIBP 2050' - 1570'
- 4) Spot 25 sxs "C" @ 1263 - 903'
- 5) Spot 25 sxs "C" + 3% CaCl<sub>2</sub>. 632 - 271' Tag @ 365'
- 6) Cut off 8-5/8" head spot 15 sxs class "C" 60' - surface
- 7) Install marker and clean location, level pits & cut off anchors

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE William R. Hansen TITLE Agent DATE 06/21/98  
TYPE OR PRINT NAME William R. Hansen TELEPHONE NO. 622-4772

(This space for State Use)

APPROVED BY [Signature] TITLE [Signature] DATE [Signature]

OCT 09 1998  
OCT 1998

4  
17 JUL 1998  
**Received**  
Hobbs  
COP