

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
061135	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Tierra Exploration, Inc.		8. Farm or Lease Name Annarco
3. Address of Operator P. O. Box 5057 Hobbs, NM 88241		9. Well No. 1
4. Location of Well UNIT LETTER <u>N</u> <u>2310</u> FEET FROM THE <u>West</u> LINE AND <u>990</u> FEET FROM <u>South</u> <u>3</u> <u>8S</u> <u>33E</u> THE <u>LINE, SECTION</u> <u>TOWNSHIP</u> <u>RANGE</u> <u>NMPM.</u>		10. Field and Pool, or Wildcat Chaveroo-San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 4407' DF		12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

1. Set CIBP at 4200'.
2. Set 20 sx plug in 4-1/2" casing on top of plug at 4200'.
3. Perfed 4-1/2" casing at 1925'. Squeezed cement with 100 sx. Left 150' plug in 4-1/2" casing 2000-1850'.
4. Set 10 sx plug at surface.
5. Welded cap on 4-1/2" casing. Set dry hole marker.
6. Cleaned location for OCD inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED San E. Clark TITLE Office Manager DATE September 25, 1985

APPROVED BY Jack Griffin TITLE OIL & GAS INSPECTOR DATE JUL 18 1986

RECEIVED

SEP 26 1985

OFFICE  
HUMAN RESOURCES