

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Injection Well	7. Unit Agreement Name No. 1 No. Caprock Queen Unit
2. Name of Operator Thunderbird Oil Corporation	8. Farm or Lease Name No. Caprock Queen Unit
3. Address of Operator P. O. Box 1778, Midland, Texas 79701	9. Well No. Tract 26, Well No. 2
4. Location of Well UNIT LETTER B, 660 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 7 TOWNSHIP 13-S RANGE 32-E NMPM.	10. Field and Pool, or Wildcat Caprock Queen (Lea)
15. Elevation (Show whether DF, RT, GR, etc.) 4378' GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8-5/8" @ 262' w/125 sx.
5-1/2" @ 2975' w/100 sx.
4-1/2" Liner @ 2907-3038'

1. Displace hole with 2500# per 100 bbls. salt base mud.
2. Set CIBP @ approximately 2800'.
3. Set 35' cement plug (5 sx.) on top of CIBP.
4. Cut off & pull 5-1/2" casing at approximately 1000'.
5. Spot 35 sx. cement plug in-and-out of 5-1/2" casing stub.
6. Spot 35 sx. cement plug in-and-out of 8-5/8" casing stub.
7. Spot 10 sx. cement plug @ surface and erect 4-1/2" regulation dry hole marker.
8. Clean up location for NMOCC inspection and approval.

100' plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Harry F. Schward</u>	TITLE <u>President</u>	DATE <u>Feb. 25, 1975</u>
--------------------------------	------------------------	---------------------------

APPROVED BY <u>B</u>	TITLE <u></u>	DATE <u></u>
----------------------	---------------	--------------

CONDITIONS OF APPROVAL, IF ANY: