

COPIES RECEIVED		
DISTRIBUTION		
T A F E		
E		
S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION, C. C.

JUN 4 11 46 AM '68

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name	
W. H. Anderson	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Tatum Wolfcamp	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator
Union Oil Company of California
3. Address of Operator
P. O. Box 671, Midland, Texas 79701
4. Location of Well
UNIT LETTER <u>H</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>7</u> TOWNSHIP <u>13-S</u> RANGE <u>36-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)
4004.3' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed plugging procedure:

1. Run tubing to 10,250' and spot plug #1 to 9,800' with 60 sacks cement.
2. Determine free point of 5-1/2" casing and shoot off casing.
3. Spot 25 sack cement plug #2 - 50' in and 50' out of 5-1/2" casing stub.
4. Spot 35 sack cement plug #3 across 8-5/8" casing shoe at 4,550' to 4,450'.
5. Determine free point of 8-5/8" casing and shoot off casing.
6. Spot 40 sack cement plug #4 - 50' in and 50' out of 8-5/8" casing stub.
7. Spot 50 sack cement plug #5 across 11-3/4" casing shoe at 380' to 280'.
8. Pull out with tubing and spot 10 sack cement plug #6 from 20' to surface, weld cap on 11-3/4" casing and install dry hole marker.

VERBAL PERMISSION TO PLUG AND ABANDON FROM MR. JOE D. RAMEY 6-3-68

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R.G. Ladd, Jr. TITLE District Drilling Supt. DATE June 1, 1968

APPROVED BY [Signature] TITLE SUPERVISOR DRILLING DATE

CONDITIONS OF APPROVAL, IF ANY:

Recovery is below 6' level. H/c 25' in.
@ 10' level