

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	C

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator TOM L. INGRAM		8. Farm or Lease Name Midhurst
3. Address of Operator POB 1757, ROSWELL, NM 88201		9. Well No. #2
4. Location of Well UNIT LETTER <u>F</u> , <u>1880</u> FEET FROM THE <u>North</u> LINE AND <u>1880</u> FEET FROM THE <u>West</u> LINE, SECTION <u>35</u> TOWNSHIP <u>12S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat So. West Gladiola Penn
15. Elevation (Show whether DF, RT, GR, etc.) 3894 KB		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

2/20/74 thru 3/24/74: Set CIBP @ 9899 and cemented with 2 sks. of cement. Perforated 1 shot per foot - 9727, 47, 56, 77, 81, 91. Acidized/1000 gals. Swb. water with no show of oil. Set CIBP @ 9715. Cemented with 4 sks. of cement. Plug back depth 9683. Perf. 1 shot per foot. 9554, 59, 77, 98, 9603, 18, 21, 26, 45, 56, 62. Acidized perfs 9554 to 9662 w/5000 gals. Swb. water with good show of oil. Prep to put on pump to test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] OPERATOR TITLE _____ DATE 3/28/74

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: _____