

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

C. L. CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-Re-entry	7. Unit Agreement Name
2. Name of Operator AMTEX ENERGY, INC.	8. Farm or Lease Name State "A"
3. Address of Operator P.O. Box 3418, Midland, Texas 79702	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> , <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>2</u> TOWNSHIP <u>14-S</u> RANGE <u>37-E</u> NMPM.	10. Field and Pool, or Wildcat King Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3839 ground level	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging procedure:

1. RIH with 6709' 2-7/8" tbg and place 35' cement plug on top of CIBP and obstruction.
2. Set 100' cement plug above the top of San Andres perms at 5066'
3. Set 100' plug from 4580' to 4680' across 8-5/8" csg shoe.
4. Set 100' plug at 1500' across salt section.
5. Set 10 sack plug at surface.
6. Cut-off well head and set up P&A marker.

see amended PA

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED William J. Savage TITLE President DATE 8-1-88

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

8