

NEW MEXICO OIL CONSERVATION COMMISSION

Orig&3cc: OCC, Hobbs  
cc: Southern Region (West Texas)  
cc: Partners  
cc: file

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> 2. Name of Operator SINCLAIR OIL CORPORATION 3. Address of Operator P. O. Box 1920, Hobbs, New Mexico 88240 4. Location of Well UNIT LETTER M, 330 FEET FROM THE South LINE AND 330 FEET FROM THE West LINE, SECTION 18 TOWNSHIP 12S RANGE 38E NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 3876' GR	7. Unit Agreement Name 8. Farm or Lease Name Rosa Shults 9. Well No. 1 10. Field and Pool, or Wildcat Gladiola Devonian 12. County Lea
--	--

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Completed Devonian perfs. 11,994-11,998'. TD 12,006', PBTD 12,000'.  
13-3/8"OD casing set @ 315' and cemented to surface.  
9-5/8"OD casing set @ 4443' and cemented w/1500 sks. to surface.  
5-1/2"OD casing set @ 12,006' and cemented w/250 sks. Top cement behind 5-1/2" csg. @ 10,980'.

PROPOSE TO PLUG AND ABANDON AS FOLLOWS:

Fill hole w/heavy mud laden material.  
Set CIBP @ approx. 11,990' w/approx. 2 sks. cement on top.  
Cut 5-1/2"OD csg. @ approx. 10,500' and pull.  
Spot 25 sks. cement plug in top of 5-1/2"OD csg. stub @ 10,500'.  
Spot 35 sks. cement plug top Penn @ 9873'.  
Spot 35 sks. cement plug top Wolfcamp @ 9464'.  
Spot 35 sks. cement plug top Abo @ 7837'.  
Spot 35 sks. cement plug top of Glorieta @ 5890'.  
Spot 25 sks. cement plug bottom of 9-5/8"OD casing @ 4443'.  
Spot 10 sks. cement in top of 9-5/8"OD csg. @ surface, install regulation dry hole marker, clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul B. [Signature] TITLE Superintendent DATE 3-4-69

APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: