

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG A WELL TO A DIFFERENT RESERVOIR. USE INDICATIONS FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG A WELL TO A DIFFERENT RESERVOIR.)		5a. Indicate Type of Lease State ☐ Fee ☒ 5. State Oil & Gas Lease No.
1. OIL WELL ☒ GAS WELL ☐ OTHER ☐ 2. Name of Operator Atlantic Richfield Company 3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240 4. Location of Well UNIT LETTER <u>N</u> <u>330</u> FEET FROM THE <u>South</u> LINE AND <u>2310</u> FEET FROM THE <u>West</u> LINE, SECTION <u>11</u> TOWNSHIP <u>13S</u> RANGE <u>38E</u> NMPM.		7. Unit Agreement Name 8. Farm or Lease Name Barnes & Golden 9. Well No. <u>1</u> 10. Field and Pool, or Wildcat Bronco Wolfcamp
15. Elevation (Show whether DF, KT, GR, etc.) 3800' GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE DRILLING OPNS. ☐ PULL OR ALTER CASING ☐ OTHER ☐ CASING TEST AND CEMENT JOB ☐ OTHER ☐		SUBSEQUENT REPORT OF: ALTERING CASING ☐ PLUG AND ABANDONMENT ☐ OTHER ☐
---	--	---

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 11,860', PBD 9623'. Presently completed unsuccessfully in the Wolfcamp zone perms 9349-9582'. All potential zones have been tested or produced in this well and no other productive possibilities exist. Propose to P&A in the following manner:

13-3/8" OD 48# csg set @ 323'. Cmdt w/400 sx. Circ to surface.

9-5/8" OD 36# csg set @ 4624'. Cmdt w/2500 sx, circ to surf.

5-1/2" OD 17 & 20# csg set @ 11,780'. Cmdt w/125 sx. TOC @ 9560'.

Cmt behind 5 1/2" csg 5000-2620' to repair casing leak.

1. RU, POH w/2-3/8" tbq, install BOP.

2. RIH w/CIBP, set BP @ 9180', dump 35' Cl C cmt (5 sx) on top of BP. Fill hole w/heavy gelled mud between all cmt plugs.

3. Spot 100' Cl C cmt cont'g 4% gel @ 4400' across top of Glorieta & Grayburg SA.

4. Cut 5 1/2" OD csg @ free point & recover (free pt estimated to be @ 2600').

5. Spot 100' Cl C cmt cont'g 4% gel across 5 1/2" OD csg stub.

6. Spot 100' Cl C cmt cont'g 4% gel inside 9-5/8" OD csg across top of salt @ 2288'.

7. Spot 10 sx Cl C cmt @ surface, install regulation dry hole marker, clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Dist. Drlg. Supv. DATE 9/17/76
 APPROVED BY [Signature] TITLE DATE
 CONDITIONS OF APPROVAL, IF ANY: