

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Skelly Oil Company	8. Farm or Lease Name Gray "B"
3. Address of Operator P. O. Box 1351, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER F 1980 FEET FROM THE North 1980 LINE AND FEET FROM West 35 14S 33E THE LINE, SECTION TOWNSHIP RANGE NMPM.	10. Field and Pool, or Wildcat Saunders Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4187.1' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has become uneconomical to operate and we propose to plug it as follows:

- 1) Rig up workover rig.
- 2) Dump 30 sacks cement from PBTD of 9927' to 9750'.
- 3) Locate free point, cut off 5-1/2" OD casing at approximately 6088' and pull.
- 4) Spot cement plugs as follows:
50 sacks across 5-1/2" OD casing stub
50 sacks across bottom of 8-5/8" at 4295'
50 sacks across top of salt at 1640'
10 sacks in top of 13-3/8" and cellar
All intervals not cemented will be filled with 10# mud.
- 5) Set marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

(Signed) D. R. Crow

SIGNED _____ TITLE **Lead Clerk** DATE **Sept. 27, 1972**

APPROVED BY **Joe D. Ramey** TITLE _____ DATE **OCT 2 1972**
Dist. 1, Supy.

CONDITIONS OF APPROVAL, IF ANY: