

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 25, 1999

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

WELL API NO. 30-025-23952
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 005370
7. Lease Name or Unit Agreement Name: Stan 'A' Com
8. Well No. One
9. Pool name or Wildcat Bagley Penn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>	2. Name of Operator J.P.H. Oil Producers
3. Address of Operator P.O. Box 565, Lovington, N.M 88260	4. Well Location Unit Letter J : 1980 feet from the FSL line and 1980 feet from the FEL line Section 09 Township 12 S Range 33 E NMPM County LEA
10. Elevation (Show whether DR, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

- PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

- REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Plug And Abandon As Follows

1. MIRU - Install ~~Boo~~ Pool With Rods & Tubing
2. Set CIBP @ ~~8200~~ With ~~20'~~ Cement On Top
3. CIR. 9.5# Mud
4. Pull ~~4 1/4"~~ Casing From as Deep as possible (EST. 7500' TOC)
5. Spot 35 SXS @ Stub & Tag 50' IN+OUT - TAG
6. Spot 35 SXS @ Casing Shoe & Tag 50' IN-OUT - TAG
7. Pull 8 5/8" Casing as Deep as possible (EST. 2500 TOC)
8. Spot 50 SXS @ Stub & Tag
9. Spot 50 SXS @ Surface casing shoe (382) 432+0332 TAG
10. Spot 10 SXS @ Surface-Cut OFF Wellhead & Anchors-Cover PIT

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jimmy Hodge TITLE Operator DATE 10-12-00
Type or print name Jimmy Hodge Telephone No. 505-396-2104
(This space for State use)

APPROVED BY Larry W. Wink TITLE Operator DATE NOV 14 2000
Conditions of approval, if any: