

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Texaco Producing Inc.	8. Farm or Lease Name E. L. Richardson
3. Address of Operator PO Box 728, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>O</u> 1980 FEET FROM THE <u>East</u> LINE AND <u>660</u> FEET FROM THE <u>South</u> LINE, SECTION <u>33</u> TOWNSHIP <u>13S</u> RANGE <u>36E</u> N.M.P.M.	10. Field and Pool, or Wildcat McDonald Upper Penn
15. Elevation (Show whether DF, RT, GR, etc.) 3964' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

P. INFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:
REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) MIRU. Pull rods and pump. Install BOP. Pull tubing.
- 2) Set CIBP at 10,250'. With dump bailer dump 4 sacks cement on plug.
- 3) Cut 5 1/2" casing at 8550' with jet cutter and pull casing.
- 4) Load hole with 10 ppg salt gel mud.
- 5) Spot 40 sacks, plug across the 5 1/2" casing stub at 8550'. - Tag
- 6) Spot 40 sacks plug at 6500'.
- 7) Spot 40 sacks plug across 8 5/8" casing shoe at 4580'. - Tag
- 8) Spot 40 sacks plug at the base of the salt at 3172'.
- 9) Spot 40 sacks plug at the top of the salt at 2493'.
- 10) Cut 8 5/8" casing at 770' with jet cutter and pull casing.
- 11) Spot 100 sacks plug across the 8 5/8" casing stub at 770'. - Tag
- 12) Spot 100 sacks plug across the 13 3/8" casing shoe at 422'.
- 13) Spot 10' plug at surface.
- 14) Install abandonment marker. RDP. Clean location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

397-3571

SIGNED Eddie W. Seay TITLE Hobbs Area Superintendent DATE Sept. 2, 1987

Eddie W. Seay

APPROVED BY Oil & Gas Inspector TITLE DATE SEP 14 1987

CONDITIONS OF APPROVAL, IF ANY: