

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
L-6877	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator		8. Farm or Lease Name	
Adobe Oil & Gas Corporation		East Tatum State Unit	
3. Address of Operator		9. Well No.	
1100 Western United Life Bldg., Midland, TX 79701		1	
4. Location of Well		10. Field and Pool, or Wildcat	
UNIT LETTER <u>A</u> , <u>660</u> FEET FROM THE <u>north</u> LINE AND <u>990</u> FEET FROM		Wildcat	
THE <u>east</u> LINE, SECTION <u>35</u> TOWNSHIP <u>12-S</u> RANGE <u>36-E</u> NMPM.			
15. Elevation (Show whether DF, RT, GR, etc.)		12. County	
Gr 3967		Lea	

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to Plug and Abandon as follows:

- Set CIBP at 12,880' w/3 sx cement on top of plug.
 - Circ hole w/9.5#/gal or heavier mud laden fluid.
 - Cut off 5-1/2" csg at 8500' + and pull out of hole.
 - Run tbg 50' inside 5-1/2" stub and spot 45 sx cement plug.
 - WOC and tag w/tbg.
 - Spot plugs at following intervals:
 - 6000-6100 - 45 sacks
 - 4650-4550 - 50 sacks. WOC and tag.
 - 2280-2180 - 50 sacks
 - 488-388 - 50 sacks
 - 20-surface- 10 sacks
 - Cut off wellhead below ground level and install dry hole marker.
- * Mud between Plugs - 9.5#
- * 24 hour notice to O.C.D.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Lie. B. C. C. C. TITLE Engineer DATE 8-6-79

APPROVED BY John W. Rungan TITLE Geologist DATE AUG 7 1979

CONDITIONS OF APPROVAL, IF ANY:

* note above