

STATE 16-2
PLUG AND ABANDONMENT

9/30/96 -10/11/96 -

MIRU WSU. N/D tree. NU BOP's. Tried to release packer. Would not release. Called NMOCD to notify of problem. Approved spotting 100 sx cement plug below packer and dispose w/100 bbls H2O. RIH w/1-11/16" jet cutter. Found SN @ 13,000'. Made cut @ 12,980' per NMOCD. Tried to POOH w/tbg. Tbg not free. MIRU Wedge W/L to RIH w/freepoint tool. State Insp. Jack Griffin on location. Cut tubing at 12,200'. POOH w/tbg. Set CIBP at stub. Dump/bail 35' cmt on plug. Spot 20 sx cmt plug at 10,000'. RIH w/5-1/2" CIBP. Set 12,190'. Spot 25 sx cmt. on top of CIBP. Cut csg. at 7253' and POOH with casing. RBIH w/tubing to 7310'. Spot cement from 7310' to 7210' across 5-1/2" csg. stub. Tag cmt. on csg stub. Plug at 7120'. Plug from 7310-7120'. Spot cmt across 8-5/8" csg. shoe. Tag cmt at 4474'. Plug from 4740' to 4474'. Pump 40 sx cmt plug. Top of plug 303'-450'. Use 10 sx cmt to surface. RDMO.