

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

# OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG-8446
7. Lease Name or Unit Agreement Name  State IQ
8. Well No. 1
9. Pool name or Wildcat Baum Upper Penn
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER
2. Name of Operator Petrus Oil Company, L. P. Bridge Oil Co. L.P.
3. Address of Operator 12377 Merit Drive, Suite 1600 Dallas, Texas 75251
4. Well Location Unit Letter K : 1980 Feet From The South Line and 1980 Feet From The West Line Section 23 Township 13S Range 32E NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

01-20-89 MIRU to Plug well. GIH to 9650' and set CIBP. Spot 20' cement on CIBP. PU to 7530' and spot 100' cement plug. Cut off 5-1/2" casing at 3657' and pull 15 jts 15.5# casing. Spott 100' plug at 5340'. Spot 360' plug at 3964'. Spot 30 sack cement plug at 420'. Spot 20 sack plug at surface. Cut off 13-3/8" casing and weld on cap. Weld on P&A marker. Well plugged and abandoned 01-26-89.

Note: hole was circulated with mud laden brine on 01-20-89.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Suzann Welch TITLE Reg. Coordinator DATE 02-10-89  
TYPE OR PRINT NAME TELEPHONE NO.

(This space for State Use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

OIL & GAS INSPECTOR

TITLE

DATE

OCT 17 1990