

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT OR (OPPL) C-101 FOR SUCH PROPOSALS.)		5a. Indicate Type of Lease State ☒ Fee ☐ 5. State Oil & Gas Lease No.																
1. ☐ OIL WELL ☒ GAS WELL ☐ OTHER- 2. Name of Operator Southland Royalty Company 3. Address of Operator 1100 Wall Towers West, Midland, Texas 79701 4. Location of Well UNIT LETTER <u>J</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM <u>East</u> <u>8</u> LINE, SECTION <u>14S</u> TOWNSHIP <u>33E</u> RANGE <u>33E</u> NMPL.		7. Unit Agreement Name 8. Farm or Lease Name Baum State 9. Well No. 1 10. Field and Pool, or Wildcat Baum (Upper Penn)																
15. Elevation (Show whether DF, RT, GR, etc.) 4245.1' GR		12. County Lea																
16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data <table border="0"> <tr> <td colspan="2">NOTICE OF INTENTION TO:</td> <td colspan="2">SUBSEQUENT REPORT OF:</td> </tr> <tr> <td>PERFORM REMEDIAL WORK ☐</td> <td>PLUG AND ABANDON ☐</td> <td>REMEDIAL WORK ☐</td> <td>ALTERING CASING ☐</td> </tr> <tr> <td>TEMPORARILY ABANDON ☐</td> <td>CHANGE PLANS ☐</td> <td>COMMENCE DRILLING OPNS. ☐</td> <td>PLUG AND ABANDONMENT ☒</td> </tr> <tr> <td>PULL OR ALTER CASING ☐</td> <td>OTHER ☐</td> <td>CASING TEST AND CEMENT JOBS ☐</td> <td></td> </tr> </table>			NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:		PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐	TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☒	PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:																
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐															
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☒															
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐																
7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.																		

1. Spot 25 sxs cmt plug from 9851-9751'.
2. Spot 25 sxs cmt plug from 9235-9135'.
3. Spot 25 sxs cmt plug from 7750-7650'. Pulled DP to 5525'.
4. Spot 40 sxs cmt from 5525-5425'. Pulled DP to 4150'.
5. Spot 40 sxs cmt from 4150-4044'. Pulled DP to 1486'.
6. Spot 40 sxs cmt from 1486-1366'. POH.
7. Spot 16 sxs cmt from 50' to surface.
8. Removed BOP & Wellhead.
9. Cleaned pits & RD rotary. Rlsd rig @ 6:30 P.M. 3-26-82.
10. Installed dry hole marker.

Above procedure approved 3-25-82 by Jerry Sexton:

I, I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CWED [Signature] TITLE District Production Manager DATE 3-31-82

APPROVED BY JERRY SEXTON TITLE DISTRICT 1 SUPR. DATE JUL 16 1982

RECEIVED

APR 5 1987

O.C.D.
HOSES OFFICE