

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2083

WELL API NO.	30-025-27994
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LG 813
7. Lease Name or Unit Agreement Name Tulk VV State	
8. Well No.	1
9. Pool name or Wildcat	Tulk Penn North Tulk Wolfcamp

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator YATES PETROLEUM CORPORATION
3. Address of Operator 105 South Fourth Street - Artesia, NM 88210	4. Well Location Unit Letter <u>I</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>660</u> Feet From The <u>East</u> Line Section <u>28</u> Township <u>14S</u> Range <u>32E</u> NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4309.8' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Notify NMOCD - Hobbs prior to commencing work.
2. Set CIBP at 9275' and dump 35' of cement on top.
3. Cut and pull 5-1/2" casing. Top of cement at 6700' (CBL Poor quality).
4. Set 100' cement plug across 5-1/2" stub.
5. Set 100' cement plug (25 sx min.) across Glorietta Top at 5584'.
6. Set 100' cement plug (25 sx min.) across 8-5/8" casing shoe at 4208'. WOC and tag this plug.
7. Set 100' (25 sx min) cement plug across Rustler top at 1470'.
8. Set 10 sx surface plug.
9. Install P&A marker.

Verbal per telecom Rex Gates (YPC) and Paul Kantz (NMOCD-Hobbs) on 10-17-94

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein (by Pamela Evans) TITLE Production Clerk DATE 10-17-94  
TYPE OR PRINT NAME Rusty Klein 505-748-1471  
TELEPHONE NO.

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

OCT 19 1994