mil 3 Supies Appropriate	Energy, I rals and	of New Mexico Natural Resource	o urces Department		Form C-103 Revised 1-1-89	)
and Office	OIL CONSER	VATION	DIVISION	WELL API NO.		]
<u>STRICT I</u> ). Box 1980, Hobbs, NM 88240	P(	D. Box 2088		30-025-	28137	
STRICT II D. Drawer DD, Artesia, NM 88210	Santa Fe, Nev	w Mexico 875	504-2088	5. Indicate Type of	TATE X FI	
STRICT III		•		6. State Oil & Gas	Lease No.	
00 Rio Brazos Rd., Aztec, NM 87410	1			V-64	4	m
DO NOT USE THIS FORM FOR P	TICES AND REPORT PROPOSALS TO DRILL OR SERVOIR. USE "APPLICAT C-101) FOR SUCH PROP	TON FOR PERMI		7. Lease Name or	Unit Agreement Name	//////
Type of Well: GAS				Paloma	a WW State	
WELL KX WELL	OTH	ER		8. Well No.		
Name of Operator YATES PETROLEUM CORI	PORATION					
Address of Operator				9. Pool name or		
105 South Fourth St	reet - Artesia, N	M 88210	<u> </u>	<u> </u>	aum Wolfcamp	
Well Location	1000	North	Line and198	0 Feet From	m The	Line
Unit Letter $F$ :	1980 Feet From The				_	0
Section 3	Township 14	S Rang	ge <u>33E</u>	NMPM	Lea	County
Section 3	10. Elevation	n (Show whether D	F, RKB, RT, GR, etc.)			
	/////////	4236	6.1' GR			
	///////		Children	Demost or Othe	er Data	
	ck Appropriate Box	to Indicate N	lature of Notice.	Report, or Othe	er Data REPORT OF	
n. Che NOTICE OF	ck Appropriate Box INTENTION TO:	to Indicate N	lature of Notice.	Report, or Othe		Г
	INTENTION TO:	to Indicate N	lature of Notice.	Report, or Otho JBSEQUENT	er Data REPORT OF: ALTERING CASING	
	INTENTION TO:	to Indicate N	Tature of Notice, SL REMEDIAL WORK			DNMENT
	INTENTION TO:	to Indicate N	Tature of Notice, SL REMEDIAL WORK COMMENCE DRILL		ALTERING CASING	DNMENT
NOTICE OF ERFORM REMEDIAL WORK	INTENTION TO:	to Indicate N	Tature of Notice, SL REMEDIAL WORK		ALTERING CASING	DNMENT [
NOTICE OF ERFORM REMEDIAL WORK [ TEMPORARILY ABANDON [ PULL OR ALTER CASING [	INTENTION TO: PLUG AND ABA CHANGE PLAN	to Indicate N ANDON	Tature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND		ALTERING CASING	DNMENT [
NOTICE OF ERFORM REMEDIAL WORK [ EMPORARILY ABANDON [ PULL OR ALTER CASING [	INTENTION TO: PLUG AND ABA CHANGE PLAN perfs in Bough	to Indicate N	Tature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER:		ALTERING CASING PLUG AND ABANDO	
NOTICE OF ERFORM REMEDIAL WORK [ EMPORARILY ABANDON [ PULL OR ALTER CASING [ DTHER: <u>Acidize existin</u> 12. Describe Proposed or Completed	INTENTION TO: PLUG AND ABA CHANGE PLAN perfs in Bough	to Indicate N	Tature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER:		ALTERING CASING PLUG AND ABANDO	
NOTICE OF ERFORM REMEDIAL WORK [ EMPORARILY ABANDON [ PULL OR ALTER CASING [ DTHER: Acidize existin 12. Describe Proposed or Completed	INTENTION TO: PLUG AND ABA CHANGE PLAN Deperts in Bough Operations (Clearly state all p	to Indicate N	Iature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER: of give pertinent dates, i		ALTERING CASING PLUG AND ABANDO	
NOTICE OF ERFORM REMEDIAL WORK [ EMPORARILY ABANDON [ PULL OR ALTER CASING [ DTHER: <u>Acidize existin</u> 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo	INTENTION TO: PLUG AND ABA CHANGE PLAN Departs in Bough Operations (Clearly state all p pugh and Upper Wol	to Indicate N	Iature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER: of give pertinent dates, i		ALTERING CASING PLUG AND ABANDO	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12. Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods,	INTENTION TO: PLUG AND ABA CHANGE PLAN Deperts in Bough Operations (Clearly state all p Dugh and Upper Wo tubing and pump.	to Indicate N	Vature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER: of give pertinent dates, i as follows:	JNG OPNS.	ALTERING CASING PLUG AND ABANDO	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB: 3 Set RBP at 9925	INTENTION TO: PLUG AND ABA CHANGE PLAN Deperts in Bough Operations (Clearly state all p Dugh and Upper Wo tubing and pump. P and packer. ± and test. Set	to Indicate N ANDON IS & WC X Derrinent details, and If camp zone packer at S	Tature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER: ad give pertiment dates, it as as follows: 9825'±. Acidi	JNG OPNS.	ALTERING CASING PLUG AND ABANDC te of starting any proposed ons 9845-9886' tubing.	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon	INTENTION TO: PLUG AND ABA CHANGE PLAN Deperts in Bough Operations (Clearly state all p Dugh and Upper Wo tubing and pump. P and packer. ± and test. Set s 15% NEFE with s	to Indicate N	Iature of Notice,         SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertiment dates, it         es as follows:         9825'±. Acidi         itor and ball         occoutt	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806'	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB: 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825'	INTENTION TO: PLUG AND ABA CHANGE PLAN Depends in Bough Operations (Clearly state all p Dugh and Upper Wol tubing and pump. P and packer. ± and test. Set s 15% NEFE with s ± and test. Set	to Indicate N	Iature of Notice,         SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertinent dates, it         es as follows:         9825'±. Acidi         itor and ball         9680'±. Acidi	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' a down tubing.	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB: 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825'	INTENTION TO: PLUG AND ABA CHANGE PLAN Depends in Bough Operations (Clearly state all p Dugh and Upper Wol tubing and pump. P and packer. ± and test. Set s 15% NEFE with s ± and test. Set	to Indicate N	Iature of Notice,         SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertinent dates, it         es as follows:         9825'±. Acidi         itor and ball         9680'±. Acidi	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' a down tubing.	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING DTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825' with 2700 gallon 5. Set RBP at 9925' to test.	INTENTION TO: PLUG AND ABA CHANGE PLAN Deperts in Bough Operations (Clearly state all p Dugh and Upper Woltubing and pump. P and packer. t and test. Set s 15% NEFE with s t and test. Set s 15% NEFE acid w t and packer at 9	to Indicate N	Iature of Notice, SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertiment dates, if         es as follows:         9825'±. Acidi         offen and ball         9680'±. Acidi         inhibitor and         ab perforation	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' down tubing. and 9845-9886	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825' with 2700 gallon 5. Set RBP at 9925' to test.	INTENTION TO: PLUG AND ABA CHANGE PLAN Deperts in Bough Operations (Clearly state all p Dugh and Upper Woltubing and pump. P and packer. t and test. Set s 15% NEFE with s t and test. Set s 15% NEFE acid w t and packer at 9	to Indicate N	Iature of Notice, SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertiment dates, if         es as follows:         9825'±. Acidi         offen and ball         9680'±. Acidi         inhibitor and         ab perforation	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' down tubing. and 9845-9886	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825' with 2700 gallon 5. Set RBP at 9925' to test. 6. Set RBP at 9280' 7 Perforate Upper	INTENTION TO: PLUG AND ABA CHANGE PLAN Deperts in Bough Operations (Clearly state all p Dugh and Upper Wolt tubing and pump. P and packer. ± and test. Set s 15% NEFE with s ± and test. Set s 15% NEFE acid w ± and packer at 9 ±. POOH with tub Wolfcamp with 20	to Indicate N ANDON IS & WC X berrinent details, and If camp zone packer at 9 cale inhibit packer at 9 cale inhibit p	Iature of Notice, SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertiment dates, if         es as follows:         9825'±. Acidi         itor and ball         9680'±. Acidi         inhibitor and         ab perforation         cker.         ollows:       9156	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' down tubing. and 9845-9886 L59' (8 holes)	
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON PULL OR ALTER CASING DTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9925' with 2700 gallon 5. Set RBP at 9925' to test. 6. Set RBP at 9280' 7. Perforate Upper and 9206, 07, 09 8. RIH w/tubing, RB	INTENTION TO: PLUG AND ABA CHANGE PLAN CHANGE PLAN CHANGE PLAN Dependions (Clearly state all p ough and Upper Wolt tubing and pump. P and packer. ± and test. Set s 15% NEFE with s ± and test. Set s 15% NEFE acid w ± and packer at 9 ±. POOH with tub Wolfcamp with 20 0, 10, 11 & 9213' BP and packer. Set	to Indicate N ANDON IS & WC X berninent details, and If camp zone packer at 9 cale inhibit packer at 9 cale inhibit p	Iature of Notice, SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertinent dates, if         es as follows:         9825'±. Acidition         <	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' and 9845-9886 159' (8 holes) arrel-15% NEFE berfs. 9206-1	[
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON PULL OR ALTER CASING DTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9925' with 2700 gallon 5. Set RBP at 9925' to test. 6. Set RBP at 9280' 7. Perforate Upper and 9206, 07, 09 8. RIH w/tubing, RB	INTENTION TO: PLUG AND ABA CHANGE PLAN CHANGE PLAN CHANGE PLAN Dependions (Clearly state all p ough and Upper Wolt tubing and pump. P and packer. ± and test. Set s 15% NEFE with s ± and test. Set s 15% NEFE acid w ± and packer at 9 ±. POOH with tub Wolfcamp with 20 0, 10, 11 & 9213' BP and packer. Set	to Indicate N ANDON IS & WC X berninent details, and If camp zone packer at 9 cale inhibit packer at 9 cale inhibit p	Iature of Notice, SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertinent dates, if         es as follows:         9825'±. Acidition         <	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' and 9845-9886 159' (8 holes) arrel-15% NEFE berfs. 9206-1	[
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825' with 2700 gallon 5. Set RBP at 9925' to test. 6. Set RBP at 9280' 7. Perforate Upper and 9206, 07, 09 8. RIH w/tubing, RH acid across perf	INTENTION TO: PLUG AND ABA CHANGE PLAN Depends in Bough Operations (Clearly state all p Dugh and Upper Wolt tubing and pump. P and packer. ± and test. Set s 15% NEFE with s ± and test. Set s 15% NEFE acid w ± and packer at 9 ±. POOH with tub Wolfcamp with 20 0, 10, 11 & 9213' BP and packer. Set	to Indicate N ANDON IS & WC X berrinent details, and If camp zone packer at 9 cale inhibit packer at 9 ith scale bing and pacholes as f (12 holes) et RBP at 9 13'. Pull with scale	Iature of Notice, SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertinent dates, it         es as follows:         9825'±. Acidition         9825'±. Acidition         9680'±. Acidition         ab perforation         cker.         0110ws:       9156         .260'± and test         packer to 918         inhibitor and	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' down tubing. and 9845-9886 159' (8 holes) arrel 15% NEFE e perfs. 9206-1 s. down tubing. CONTINUED	[
NOTICE OF PERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825' with 2700 gallon 5. Set RBP at 9925' to test. 6. Set RBP at 9280' 7. Perforate Upper and 9206, 07, 09 8 RIH w/tubing, RB	INTENTION TO: PLUG AND ABA CHANGE PLAN Depends in Bough Operations (Clearly state all p Dugh and Upper Wolt tubing and pump. P and packer. ± and test. Set s 15% NEFE with s ± and test. Set s 15% NEFE acid w ± and packer at 9 ±. POOH with tub Wolfcamp with 20 0, 10, 11 & 9213' BP and packer. Set	to Indicate N ANDON IS & WC X berrinent details, and If camp zone packer at 9 cale inhibit packer at 9 cale inhibit p	Ature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER: ad give pertiment dates, i es as follows: 9825'±. Acidi itor and ball 9680'±. Acidi inhibitor and ab perforation cker. ollows: 9156 260'± and tes packer to 918 inhibitor and mibitor and	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' and 9845-9886 159' (8 holes) arrel-15% NEFE berfs. 9206-1	[
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825' with 2700 gallon 5. Set RBP at 9925' to test. 6. Set RBP at 9280' 7. Perforate Upper and 9206, 07, 09 8. RIH w/tubing, RH acid across perf	INTENTION TO: PLUG AND ABA CHANGE PLAN Depends in Bough Operations (Clearly state all p Dugh and Upper Wolt tubing and pump. P and packer. ± and test. Set s 15% NEFE with s ± and test. Set s 15% NEFE acid w ± and packer at 9 ±. POOH with tub Wolfcamp with 20 0, 10, 11 & 9213' BP and packer. Set	to Indicate N ANDON IS & WC X berrinent details, and If camp zone packer at 9 cale inhibit packer at 9 cale inhibit p	Iature of Notice, SL         REMEDIAL WORK         COMMENCE DRILL         CASING TEST AND         OTHER:         ad give pertinent dates, it         es as follows:         9825'±. Acidition         9825'±. Acidition         9680'±. Acidition         ab perforation         cker.         0110ws:       9156         .260'± and test         packer to 918         inhibitor and	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' down tubing. and 9845-9886 159' (8 holes) arrel 15% NEFE e perfs. 9206-1 s. down tubing. CONTINUED DATE6-16 505-748-	[ 3'
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 7 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825' with 2700 gallon 5. Set RBP at 9825' to test. 6. Set RBP at 9280' 7. Perforate Upper and 9206, 07, 09 8. RIH w/tubing, RF acid across perf with 2000 gallor I hereby certify the the information at SIGNATURE	INTENTION TO: PLUG AND ABA CHANGE PLAN CHANGE PLAN Dependions (Clearly state all p Dugh and Upper Woll tubing and pump. P and packer. t and test. Set s 15% NEFE with s t and test. Set s 15% NEFE acid w t and packer at 9 t. POOH with tub Wolfcamp with 20 0, 10, 11 & 9213' BP and packer. Set torations 9206-927 IS 15% NEFE acid w torations 9206-927 IS 15% NEFE acid w	to Indicate N ANDON IS & WC X berrinent details, and If camp zone packer at 9 cale inhibit packer at 9 cale inhibit p	Ature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER: ad give pertiment dates, i es as follows: 9825'±. Acidi itor and ball 9680'±. Acidi inhibitor and ab perforation cker. ollows: 9156 260'± and tes packer to 918 inhibitor and mibitor and	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' down tubing. and 9845-9886 159' (8 holes) arrel 15% NEFE e perfs. 9206-1 s. down tubing. CONTINUED 	[ 3'
NOTICE OF ERFORM REMEDIAL WORK EMPORARILY ABANDON OULL OR ALTER CASING OTHER: Acidize existin 12 Describe Proposed or Completed work) SEE RULE 1103. Propose to acidize Bo 1. POOH with rods, 2. RIH w/tubing, RB 3. Set RBP at 9925' with 1300 gallon 4. Set RBP at 9825' with 2700 gallon 5. Set RBP at 9925' to test. 6. Set RBP at 9280' 7. Perforate Upper and 9206, 07, 09 8. RIH w/tubing, RF acid across perf with 2000 gallon I hereby centry that the information at	INTENTION TO: PLUG AND ABA CHANGE PLAN CHANGE PLAN Dependions (Clearly state all p Dugh and Upper Woll tubing and pump. P and packer. t and test. Set s 15% NEFE with s t and test. Set s 15% NEFE acid w t and packer at 9 t. POOH with tub Wolfcamp with 20 0, 10, 11 & 9213' BP and packer. Set torations 9206-927 IS 15% NEFE acid w torations 9206-927 IS 15% NEFE acid w	to Indicate N ANDON IS & WC X berrinent details, and If camp zone packer at 9 cale inhibit packer at 9 cale inhibit p	Ature of Notice, SL REMEDIAL WORK COMMENCE DRILL CASING TEST AND OTHER: ad give pertiment dates, i es as follows: 9825'±. Acidi itor and ball 9680'±. Acidi inhibitor and ab perforation cker. ollows: 9156 260'± and tes packer to 918 inhibitor and mibitor and	JNG OPNS.	ALTERING CASING PLUG AND ABANDO PLUG AND ABANDO te of starting any proposed ons 9845-9886' tubing. ons 9737-9806' down tubing. and 9845-9886 159' (8 holes) arrel-15% NEFE e perfs. 9206-1 s down tubing. CONTINUED DATE6-16 505-748- 	[ 3'

- Submit 3 Copies to Appropriate	State of New M Energy, M <sup>1</sup> vals and Natural	Mexico Resources Department	Form C-103 Revised 1-1-8	9
District Office DISTRICT I P.O. Box 1980, Hobbs, NM 88240	OIL CONSERVATI P.O. Box 2	.088	WELL API NO. 30-025-28137	
DISTRICT II P.O. Drawer DD, Artesia, NM 88210	Santa Fe, New Mexic	xo 87504-2088	5. Indicate Type of Lease STATE X	TEE
DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410		•	6. State Oil & Gas Lease No. V-644	mm
·		UC119		
( DO NOT USE THIS FORM FOR P	TICES AND REPORTS ON W ROPOSALS TO DRILL OR TO DEEP ERVOIR. USE "APPLICATION FOR I C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name	
1. Type of Well: OL. GAS WELL	OTHER	· · · · · · · · · · · · · · · · · · ·	Paloma WW State	
WELL KA WELL			8. Well No.	
2. Name of Operator YATES PETROLEUM CORE	ORATION		9. Pool name or Wildcat	
a this of Operator		10	South Baum Wolfcamp	
105 South Fourth Str	ceet – Artesia, NM 882	10		
4. Well Location	North	Line and 198	30 Feet From The West	Line
Unit LetterF :	1980 Feet From The North			County
Section 3	Township 14S	Range 33E	NMPM Lea	
Section 3	10. Elevation (Show wh	hether DF, RKB, RT, GR, etc.)		
	///////	4236.1' GR	Report or Other Data	
11. Che	ck Appropriate Box to Indic	ate Nature of Nonce,	JBSEQUENT REPORT OF:	
11.	INTENTION TO:	SU	JBSEQUENT REFORT OF	
-	-			i L
	PLUG AND ABANDON			[]
	-			[]
PERFORM REMEDIAL WORK	PLUG AND ABANDON	L		[]
PERFORM REMEDIAL WORK	PLUG AND ABANDON CHANGE PLANS			[]
PERFORM REMEDIAL WORK	PLUG AND ABANDON CHANGE PLANS	COMMENCE DRILL CASING TEST AND COTHER:		
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: Perforate and ac 12 Describe Proposed or Completed work) SEE RULE 1103. 9. Set RBP at 9180' Pull packer to 9 with scale inhib 10. Set RBP at 9260' 11. Set RBP at 9260' 12. Perforate Upper 13. RIH with tubing Set packer at 89 with scale inhib	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS Charly state all pertinent de t and test. Spot 1 bar 100't. Acidize perfora itor and ball sealers d t and packer at 9100't. t. POOH with tubing ar Wolfcamp with 8 holes a	COMMENCE DRILL CASING TEST AND CASING TEST AND OTHER: trails, and give periment dates, rel 15% NEFE acid tions 9156-9159' with lown tubing. Swab perforation of packer. as follows: 9038, rrel 15% NEFE acid tions 9038-9041' with	LING OPNS. PLUG AND ABAND D CEMENT JOB	ONMENT
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: Perforate and ad 12 Describe Proposed or Completed work) SEE RULE 1103. 9. Set RBP at 9180' Pull packer to 9 with scale inhib 10. Set RBP at 9260' 11. Set RBP at 9260' 12. Perforate Upper 13. RIH with tubing Set packer at 89 with scale inhib 14. Swab perforation 15. Pull RBP's to 92 16. Put on pump.	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS Change PLANS Control of the second state all periment de t and test. Spot 1 bar 100't. Acidize perfora itor and ball sealers d t and packer at 9100't. t. POOH with tubing ar Wolfcamp with 8 holes a and packer. Spot 1 bar 70't. Acidize perforat ontor and ball sealers on 9038-9041' to test. 100't and 9280't.	COMMENCE DRILL CASING TEST AND CASING TEST AND OTHER: tails, and give periment dates, rel 15% NEFE acid tions 9156-9159' with lown tubing. Swab perforation d packer. as follows: 9038, rrel 15% NEFE acid tions 9038-9041' with down tubing.	LING OPNS. PLUG AND ABAND D CEMENT JOB including estimated date of starting any propose across perforations 9156-9 with 2000 gallons 15% NEFE ns 9156-9213' to test. 39, 40 & 9041' (2 SPF).	ONMENT
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: Perforate and ad 12 Describe Proposed or Completed work) SEE RULE 1103. 9. Set RBP at 9180' Pull packer to 9 with scale inhib 10. Set RBP at 9260' 11. Set RBP at 9260' 12. Perforate Upper 13. RIH with tubing Set packer at 89 with scale inhib 14. Swab perforation 15. Pull RBP's to 92 16. Put on pump.	PLUG AND ABANDON CHANGE PLANS cidize Operations (Clearly state all periment de t and test. Spot 1 bar 100't. Acidize perfora itor and ball sealers d t and packer at 9100't. t. POOH with tubing an Wolfcamp with 8 holes a and packer. Spot 1 bar 70't. Acidize perforat oitor and ball sealers of s 9038-9041' to test. 100't and 9280't.	COMMENCE DRILL CASING TEST ANI CASING TEST ANI OTHER: etails, and give periment dates, rel 15% NEFE acid tions 9156-9159' with lown tubing. Swab perforation of packer. as follows: 9038, rrel 15% NEFE acid tions 9038-9041' with down tubing.	LING OPNS. PLUG AND ABAND D CEMENT JOB	ONMENT
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: Perforate and ad 12 Describe Proposed or Completed work) SEE RULE 1103. 9. Set RBP at 9180' Pull packer to 9 with scale inhib 10. Set RBP at 9260' 11. Set RBP at 9260' 12. Perforate Upper 13. RIH with tubing Set packer at 89 with scale inhib 14. Swab perforation 15. Pull RBP's to 91 16. Put on pump. NOTE: WILL BE COMMING I hereby ceruly that be information ab SIONATURE	PLUG AND ABANDON CHANGE PLANS Cidize Operations (Clearly state all periment de t and test. Spot 1 bar 100't. Acidize perfora itor and ball sealers d t and packer at 9100't. t. POOH with tubing an Wolfcamp with 8 holes a and packer. Spot 1 bar 070't. Acidize perforat bitor and ball sealers of s 9038-9041' to test. 100't and 9280't.	COMMENCE DRILL CASING TEST ANI CASING TEST ANI OTHER: etails, and give periment dates, rel 15% NEFE acid tions 9156-9159' with lown tubing. Swab perforation of packer. as follows: 9038, rrel 15% NEFE acid tions 9038-9041' with down tubing.	LING OPNS. PLUG AND ABAND D CEMENT JOB including estimated date of starting any propose across perforations 9156-9 with 2000 gallons 15% NEFE ns 9156-9213' to test. 39, 40 & 9041' (2 SPF).	ONMENT
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: Perforate and ac 12 Describe Proposed or Completed work) SEE RULE 1103. 9. Set RBP at 9180' Pull packer to 9 with scale inhib 10. Set RBP at 9260' 11. Set RBP at 9260' 12. Perforate Upper 13. RIH with tubing Set packer at 89 with scale inhib 14. Swab perforation 15. Pull RBP's to 92 16. Put on pump. NOTE: WILL BE COMMING I hereby ceruly that be information ab	PLUG AND ABANDON CHANGE PLANS Cidize Operations (Clearly state all periment de t and test. Spot 1 bar 100't. Acidize perfora itor and ball sealers d t and packer at 9100't. t. POOH with tubing an Wolfcamp with 8 holes a and packer. Spot 1 bar 070't. Acidize perforat bitor and ball sealers of s 9038-9041' to test. 100't and 9280't.	COMMENCE DRILL CASING TEST ANI CASING TEST ANI OTHER: etails, and give periment dates, rel 15% NEFE acid tions 9156-9159' with lown tubing. Swab perforation of packer. as follows: 9038, rrel 15% NEFE acid tions 9038-9041' with down tubing.	LING OPNS. PLUG AND ABAND D CEMENT JOB including estimated date of starting any propose across perforations 9156-9 with 2000 gallons 15% NEFE ns 9156-9213' to test. 39, 40 & 9041' (2 SPF). across perforations 9038-9 ith 2000 gallons 15% NEFE a ion Clerk DATE 6-16 505-748	ONMENT
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: Perforate and ad 12 Describe Proposed or Completed work) SEE RULE 1103. 9. Set RBP at 9180' Pull packer to 9 with scale inhib 10. Set RBP at 9260' 11. Set RBP at 9260' 12. Perforate Upper 13. RIH with tubing Set packer at 89 with scale inhib 14. Swab perforation 15. Pull RBP's to 91 16. Put on pump. NOTE: WILL BE COMMING I hereby ceruly that be information ab SIONATURE	PLUG AND ABANDON CHANGE PLANS Cidize Operations (Clearly state all periment de t and test. Spot 1 bar 100't. Acidize perfora itor and ball sealers d t and packer at 9100't. t. POOH with tubing an Wolfcamp with 8 holes a and packer. Spot 1 bar 070't. Acidize perforat bitor and ball sealers of s 9038-9041' to test. 100't and 9280't.	COMMENCE DRILL CASING TEST ANI CASING TEST ANI OTHER: etails, and give periment dates, rel 15% NEFE acid tions 9156-9159' with lown tubing. Swab perforation of packer. as follows: 9038, rrel 15% NEFE acid tions 9038-9041' with down tubing.	LING OPNS. PLUG AND ABAND D CEMENT JOB including estimated date of starting any propose across perforations 9156-9 with 2000 gallons 15% NEFE ns 9156-9213' to test. 39, 40 & 9041' (2 SPF). across perforations 9038-9 ith 2000 gallons 15% NEFE a ion Clerk DATE 6-16 505-748 TELEPHONE NC	ONMENT