

5. Pull tubing up to 9,350'. Spot a 25 sx Class "H" cement plug from 9,124' to 9,350' (226') across top of Wolfcamp.
6. Pull tubing up to 5,755'. Spot a 25 sx Class "H" cement plug from 5,529' to 5,755' (226') across top of Glorietta. TOOH with tubing.
7. RU wireline company and TIH. Cut-off 5-1/2" casing at 4,250' and pull 5-1/2" casing.
8. TIH with tubing to 4,350' (100' into top of 5-1/2" casing stub). Spot a 75 sx Class "H" cement plug from 4,050' to 4,350'.
9. Pull tubing up to 2,210'. Spot an 80 sx Class "H" cement plug from 1,946' to 2,210' (264') across the top of salt.
10. Pull tubing up to 85' below ground level. Spot a 25 sx Class "H" cement plug from 3' to 85'. Cut-off casing 3' below ground level and permanently mark location as per NMOCC requirements.
11. Reclaim location as soon as possible.

Apache wishes to start P&A operations at 8:00 am, Friday, December 5, 1986.