

5. Pull DP up and spot a 100' plug (50 sxs) from 4,147'-4,247' (8-5/8" casing shoe).
6. Pull DP up and spot a 100' plug (50 sxs) from 2,100'-2,200' (Top of Salt).
7. Pull DP up and spot a 34' plug (10 sxs) from 3'-37'.
8. Cut-off wellhead equipment and 8-5/8"/13-3/8" casing 3' below ground level.
9. Cap well with regulation dry hole marker.
10. All casing was left in hole.
11. The location will be totally restored as soon as weather conditions allow.