

6. Pull DP up and spot a 100' plug (50 sxs) from 2100-2200' (Top of Salt).
7. Pull DP up and spot a 34' plug (10 sxs) from 3' - 37'.
8. Cut-off wellhead equipment and 8-5/8"/13-3/8" casing 3' below ground level.
9. Cap well with regulation dry hole marker.
10. Totally restore location to surface owner's satisfaction.