

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

5. Lease Designation and Serial No.

FEDERAL NM 37611

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

SCOTT FEDERAL #2 SWD

9. API Well No.

30-041-20637

10. Field and Pool, or Exploratory Area

SWD MONTOYA

11. County or Parish, State

ROOSEVELT

**SUBMIT IN TRIPLICATE**

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other SALT WATER DISPOSAL

2. Name of Operator

EP OPERATING LIMITED PARTNERSHIP

3. Address and Telephone No.

6 DESTA DRIVE, SUITE 5150, MIDLAND, TX 79705-5510

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit Letter B, 660' FNL & 1980' FEL of Sec. 20,  
Township 4 South, Range 33 East, NMPM, ROOSEVELT COUNTY

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent  
☒ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other PLUG & ABANDON
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

11-22-94: Set CIBP @ 8642'. Circulate 100 Bbls. mud gel. Spot 25 sx. cmt. on top of CIBP to 8500'± TOC-CALC. Stand back 6200' tbg. Lay down rest.

11-23-94: RIH with tbg. to 6008'. Circ. 50 bbls. mud gel. Spot 25 sx. cmt. to 5788'± TOC-CALC. Cut 5½" csg. @ 3000'. Pull csg. RIH with tbg. to 3057 feet. CIRC. 30 bbls. mud gel. Spot 40 sx. cmt. to 2923'. Stand back tbg.

11-25-94: RIH with tbg. Tag TOC at 2923'. Circ. mud gel to surface. Lay down tbg. to 2045'. Spot 60 sx. cmt. to 1885'± TOC-CALC. WOC. Tag TOC @ 1890'. Lay down tbg. to 1000'. Spot 50 sx. cmt. to 866'± TOC-CALC. Lay down tbg. to 30'. Spot 10 sx. cmt. to surface. Install dry hole marker.

14. I hereby certify that the foregoing is true and correct

Signed Brian Sherman

Title DIST. PROD. MGR.

Date 3-15-95

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date