STATE OF NEW MEXICO ENERGY AND MINERALS DEPARTMENT

- 12 J 20 OCI ATTIME			
, ** (*** ********	T	·	
DISTRIBUTION			
SANTA FE			
FILE			
U.S.C.S.			
LAND OFFICE			
OPERATOR			

UIL CONSERVATION DIVISION P. O. BOX 2088 SANTA FE, NEW MEXICO 87501

Form	(-)	n a	
	-		
Revis	e d	10-	١.

U.S.C.S.	Sa. Indicate Type of Lease
LAND OFFICE	State Tee X
OPERATOR	5. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	XIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII
1. OIL SAS (7, Unit Agreement Name
WELL OTHER- DRY HOLE	
2. Name of Operator Culf Engage Producing Company	8. Farm or Lease Name
Gulf Energy Producing Company 1. Address of Operator	Taylor
P.O. Box 32999 San Antonio, Texas 78216	9, Well No.
4. Location of Well	1
	10. Field and Pool, or Wildcan
UNIT LETTER C 660 FEET FROM THE NORTH LINE AND 1980	Undesignated
West LINE, SECTION 11 TOWNSHIP 6S 33E	
THE LINE, SECTION TOWNSHIP RANGENMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
	Roosevelt
16	
Check Appropriate Box To Indicate Nature of Notice, Report or Oth NOTICE OF INTENTION TO:	
SUBSEQUENT	REPORT OF:
PERFORM REMEDIAL WORK	_
TEMPORARILY ABANDON COMMENCE DRILLING OPHS.	ALTERING CASING
PULL OF ALTER CASING TEST AND CEMENT JOB	PLUE AND ABANDONMENT
OTHER	
OTHER	
22 Describe Bronzed or Completed On anti-	
 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including e work) SEE RULE 1103. 	stimated date of starting any propose
JULY 10, 1983;	
	•
Set CIBP at 7100'. Spot 35' cement plug on CIBP.	
Load hole with salt gel mud.	
Cut off $5\frac{1}{2}$ " csg. at 5200' and spot 100' cement plug at cut off point. Tag	plug with tbg.
Set 100' cement plug at 4440'	
Set 100' cement plug at '3500' in and out of intermediate casing shoe. Tag	nlug with the.
	brag with tog.
Set 100' cement plug at 1500'.	
	•
Set 10 sack cement plug at surface, weld on cap and errect dry hole marke	r.
Set 10 sack cement plug at surface, weld on cap and errect dry hole marke	r.
Set 10 sack cement plug at surface, weld on cap and errect dry hole marke	r.
Set 10 sack cement plug at surface, weld on cap and errect dry hole marke NOTE: VERBAL APPROVAL WAS PREVIOUSLY GRANTED TO COMMENCE THE ABOVE PROCE	

CRIGINAL SIGNED BY JERRY SEXTON

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

APR 1 0 1985

July 10, 1983.

***** Regulatory Administrator