

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-041-20691</u>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-760
7. Lease Name or Unit Agreement Name Roosevelt 9 State
8. Well No. 1
9. Pool name or Wildcat <u>East Jannayhill Fusselman</u> Wildcat

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator OGS Operating Co., Inc.	
3. Address of Operator 550 W. Texas, Suite 1140, Midland, Texas 79701	
4. Well Location Unit Letter <u>L</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>990</u> Feet From The <u>West</u> Line Section <u>9</u> Township <u>6-S</u> Range <u>34-E</u> NMPM <u>Roosevelt</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull production equipment.
2. Set CIBP @ 7690'. Cap with 7 sks. of cement.
3. Circulate hole with mud.
4. Spot 35 sks. of cement @ 4750'.
5. Cut and pulled 1960' of 5 1/2" casing.
6. Spot 40 sks. of cement @ 2014'. Tagged plug @ 1888'.
7. Spot 10 sk. surface plug.
8. Erect dry hole marker. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE G. A. Baber TITLE President, Baber Well Serv DATE 7-14-89

TYPE OR PRINT NAME G. A. Baber TELEPHONE NO. 505-393-5516

(This space for State Use) Jack Griffin
APPROVED BY David Smith TITLE OIL & GAS INSPECTOR DATE OCT 10 1989

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

AUG 28 1989

1
OCD
HOBBS OFFICE